DS434

November 2017145 MarchApril 2018

10 4

IAEA SAFETY STANDARDS

for protecting people and the environment

Status: Step <u>1019</u> Second review of the draft safety guide by the Safety Standards Committees Addressing Members States- comment For submission to SSCs	Formatted: Font: Bold
Reviewed in NSOC (Asfaw)	Formatted: Complex Script Font: Not Bold

3015

Radiation Safety of Accelerator Based

Radioisotope Production Facilities

DRAFT SAFETY GUIDE No. SSG-

DS434

IAEA

International Atomic Energy Agency

CONTENTS

1.	INTRODUCTION 1	Field Code Changed
	BACKGROUND 1	Field Code Changed
	OBJECTIVE	Field Code Changed
	SCOPE 2	Field Code Changed
	STRUCTURE	Field Code Changed
2.	JUSTIFICATION OF PRACTICES	Field Code Changed
3.	TYPES OF RADIOISOTOPE PRODUCTION FACILITY	Field Code Changed
4.	DUTIES AND RESPONSIBILITIES	Field Code Changed
	GENERAL	Field Code Changed
	MANAGEMENT OF RADIATION SAFETY AND SAFETY CULTURE	Field Code Changed
	RADIATION PROTECTION OFFICER	Field Code Changed
	QUALIFIED EXPERT OR RADIATION PROTECTION ADVISER	Field Code Changed
	WORKERS	Field Code Changed
		Field Code Changed
	LOCAL RULES AND PROCEDURES	Field Code Changed
5.	SAFETY ASSESSMENT	Field Code Changed
	GENERAL	Field Code Changed
	PURPOSE AND DEVELOPMENT PROCEDURE	Field Code Changed
	RESPONSIBILITY FOR SAFETY ASSESSMENT DEVELOPMENT	Field Code Changed
	SAFETY ARRANGEMENTS	Field Code Changed
6.	RADIATION PROTECTION PROGRAMME	Field Code Changed
	GENERAL	Field Code Changed
	STRUCTURE OF THE RADIATION PROTECTION PROGRAMME	Field Code Changed
	MANAGEMENT STRUCTURE AND POLICIES	Field Code Changed

	HEALTH SURVEILLANCE PROGRAMME	<u>3931</u>	Field Code Changed
	RADIATION SAFETY COMMITTEE	<u>3932</u>	Field Code Changed
7.	EDUCATION AND TRAINING	<u>4132</u>	Field Code Changed
	GENERAL	41 32	Field Code Changed
		4100	
	TRAINING PROGRAMME	<u>4133</u>	Field Code Changed
	STRUCTURE AND CONTENT OF THE TRAINING COURSE	<u>42</u> 34	Field Code Changed
	REFRESHER TRAINING	45 36	Field Code Changed
8.	INDIVIDUAL MONITORING OF WORKERS	<u>46</u> 37	Field Code Changed
	INDIVIDUAL DOSE ASSESSMENT AND RECORD KEEPING	4637	Field Code Changed
	EXTERNAL DOSIMETRY	<u>47</u> 38	Field Code Changed
	INTERNAL DOSIMETRY	<u>5041</u>	Field Code Changed
		5140	
	INVESTIGATION OF OVEREXPOSURES [2]	<u>51</u> 4 2	Field Code Changed
9.	WORKPLACE MONITORING	53 43	Field Code Changed
•		52.42	
	RADIATION MONITORS	<u>53</u> 43	Field Code Changed
10.	ENVIRONMENTAL MONITORING AND EFFLUENT DISCHARGE	6149	Field Code Changed
A			-
	ENVIRONMENTAL MONITORING	<u>61</u> 4 9	Field Code Changed
	EFFLUENT DISCHARGE	<u>61</u> 50	Field Code Changed
	MONITORING OF AIRBORNE EFFLUENTS	6250	Field Code Changed
	MONITORING OF LIQUID EFFLUENTS	<u>6551</u>	Field Code Changed
	MINIMIZING EFFLUENT DISCHARGES	<u>6552</u>	Field Code Changed
	FILTERING OF AIRBORNE EMISSIONS	6652	Field Code Changed
	TILIERING OF AIRBORINE EMISSIONS	<u>0092</u>	Field Code Changed
11.	PERSONAL PROTECTIVE EQUIPMENT	<u>69</u> 55	Field Code Changed
12.	NUCLEAR SECURITY CONSIDERATIONS	<u>71</u> 57	Field Code Changed
12	TESTING AND MAINTENANCE OF FOURMENT IL DON'T TUNIZ VOL		Field Code Changed
13.	TESTING AND MAINTENANCE OF EQUIPMENT [I DON'T THINK YOU	7250	Field Code Changed
	CAN TEST RECORDS]	<u>/ 3</u> 38	

	PERIODIC TESTS	<u>7359</u>	Field Code Changed
	RECORDS	<u>74</u> 60	Field Code Changed
	FACILITY MAINTENANCE AND MODIFICATION	<u>74</u> 60	Field Code Changed
14.	RADIOACTIVE WASTE MANAGEMENT AND DECOMMISSIONING	<u>7661</u>	Field Code Changed
	CHARACTERIZATION OF RADIOACTIVE WASTE	<u>7763</u>	Field Code Changed
	WASTE MINIMIZATION [ONLY SF-1 CONTAINS PRINCIPLES]	<u>7863</u>	Field Code Changed
	HANDLING AND PROCESSING OF RADIOACTIVE WASTE	<u>79</u> 64	Field Code Changed
	ERROR! HYPERLINK REFERENCE NOT VALID. HO YOU NEED THIS		
	HEADING?]	 65	
	ON-SITE STORAGE OF RADIOACTIVE WASTE	<u>8065</u>	Field Code Changed
	PREPARATION OF WASTE SHIPMENTS	<u>81</u> 66	Field Code Changed
15.	TRANSPORT OF RADIOACTIVE MATERIAL	<u>82</u> 66	Field Code Changed
	TRANSPORT REQUIREMENTS	82 66	Field Code Changed
16.	EMERGENCY PREPAREDNESS AND RESPONSE	<u>84</u> 68	Field Code Changed
	GENERAL	<u>84</u> 68	Field Code Changed
	EMERGENCY PLANS AND PROCEDURES	<u>85</u> 69	Field Code Changed
	EMERGENCY EQUIPMENT	<u>87</u> 70	Field Code Changed
	TRAINING AND EXERCISES	88 71	Field Code Changed
	REPORTING		Field Code Changed
		<u>90</u> 75	
REF	TERENCES	<u>92</u> 75	Field Code Changed
ANN	NEX I KEY RADIATION SAFETY ISSUES TO BE TAKEN INTO ACCOUNT		Field Code Changed
1111	WHEN PLANNING THE PRODUCTION OF ACCELERATOR BASED		
	RADIOISOTOPES	<u>96</u> 79	
ANN	NEX II EXAMPLE OF IMMEDIATE ON-SITE RESPONSE ACTIONS IN		Field Code Changed
	CASE OF AN EMERGENCY AT A RADIOISOTOPE PRODUCTION	0700	
	FACILITY	<u>97</u> 80	

Field Code Changed

1. INTRODUCTION

BACKGROUND

1.1. Radionuclides are used worldwide in a range of medical, industrial, research and academic applications that bring many benefits to humankind. Most of these radionuclides are produced in reactors and particle accelerators. The ff acilities which that produce radionuclides and the facilities in which radionuclides are processed are referred to collectively as 'radioisotope production facilities'. The operation of reactors and particle accelerators and the subsequent processing of radioactive material can present significant radiation hazards to workers, members of the public, and the environment unless these facilities are properly controlled.

1.2. In $20\underline{1703}$, there were $2\underline{378}$ research reactors in operation, of which approximately $\underline{70}$ <u>83</u> were deemed useful for regular radioisotope production [1]. In $20\underline{1706}$, it was estimated that there were approximately $\underline{350}$ —<u>11700 clinical accelerators</u>evelotrons in operation worldwide, including both linear accelerators and cyclotrons, which that were being used to some extent for radioisotope production [2]. The number of institutions that operate cyclotrons and manufacture and distribute radiopharmaceuticals that are used in positron emission tomography (<u>PET)</u> and single photon emission computed tomography (<u>SPECT)</u>-is significant and growing.

1.3. The-IAEA Safety Standards Series No. GSR Part 3, Radiation Protection and Safety of Radiation Sources: International Basic Safety Standards [3] establishes the basic requirements for protection of people against exposure to ionizing radiation and for the safety of radiation sources². The implementation-application of these requirements at radioisotope production facilities is intended to prevent accidents and, generally, to provide for the best possible protection and safety measures under the prevailing circumstances. The magnitudes and likelihood of exposures and the number of individuals exposed are required to be kept as low as reasonably achievable, economic and societal factors being taken into account.

Formatted: Left

Formatted: Tab stops: 1 cm, List tab + Not at 0.63 cm

¹ The <u>word term</u> 'radioisotope' is commonly used in the context of the facilities considered in this Safety Guide and is therefore retained here. Strictly, the word 'radionuclide' <u>should ought to</u> be used or the word <u>'radioisotope' would need to be</u> qualified by the name of the element to which it relates <u>, for example, (e.g. a</u> radioisotope of cobalt).

 $^{^2}$ The term 'radiation source' includes radioactive sources and radiation generators. 'Radiation' as used in the IAEA ssafety sstandards means ionizing radiation.

1.4. Unless otherwise stated, terms are used with the meanings ascribed to them in the IAEA Safety Glossary (2016 web Edition) [4] and the definitions provided in GSR Part 3 [3].

OBJECTIVE

1.5. The objective of this Safety Guide is to provide recommendations on how to meet the requirements of GSR Part 3 [3] with regard to radioisotope production facilities. This Safety Guide provides specific, practical recommendations on the safe design and operation of radioisotope production these facilities for use by operating organizations, the designers of these facilities, and by regulatory bodies.

SCOPE

1.6. This Safety Guide addresses the radiation safety and protection aspects of the process whereby in which radioisotopes that have been are produced in accelerators (principally cyclotrons), and of the process in which radioisotopes that have been produced in accelerators, or have been purified from other sources, are processed into radioactive products for subsequent use in, for example, in-nuclear medicine. [pls_check___2_things, right? a) production of isotopes and b) processing of isotopes] It also addresses elements of the design and operation of accelerators (principally cyclotrons) that pertain directly to the production of radioisotopes.

1.7. The following types of facilityies that produce radioisotopes are within the scope of this Safety Guide:

- (a) Facilities that process targets that have been irradiated by a charged particle beam of an accelerator to produce radioisotopes;
- (b) Accelerator facilities with energies of less than 70 MeV/nucleon that are operated principally to produce radioisotopes. This <u>document-Safety Guide</u> addresses these in the following four <u>categories-types [is this OK? we have so many other 'categories' in this Safety Guide</u> and you never refer to these groupings again as categories] of accelerators:
 - (i) Low energy (<_20 MeV-/nucleon) cyclotrons <u>used</u> for medical radioisotope production;
 - (ii) 20 40 MeV/-nucleon <u>cyclotrons used for radio</u>isotope production-<u>cyclotrons</u>;
 - (iii) > 40 MeV/-nucleon cyclotrons <u>used</u> for <u>mixed-both</u> research and radioisotope production;

Formatted: Left

Formatted: Left

(iv) Linear accelerators used for radioisotope production.

1.8. The use of radioactive material following its manufacture, and <u>the</u> standards and quality assurance procedures that pertain to its production, are outside the scope of this <u>Safety</u> <u>Guidedocument</u>. The production of fissile material is outside the scope of this <u>Safety</u> <u>Guidedocument</u>.

1.9. The design and operation of reactors is outside the scope of this <u>Safety Guide</u>; document to avoid duplication with a number of IAEA publications on research reactors<u>safety</u> requirements for research reactors are established in IAEA Safety Standards Series No. SSR-<u>3</u>, Safety of Research Reactors [5].

1.10. Centralized radiopharmacies that formulate-manufacture [?] radiopharmaceuticals from bulk quantities of radioisotopes or generators are outside the scope of this <u>Safety</u> <u>Guidedocument</u>.

1.11. Radiation generators (e.g. linear accelerators used in radiotherapy applications) that produce radioisotopes as a by-product of their operation are outside the scope of this <u>Safety</u> <u>Guidedocument</u>.

1.12. Consideration of non-radiological related-risks and of the benefits of radioisotopes that are produced in radioisotope production facilities are outside the scope of this Safety Guide.

1.13. The Safety Guide also provides information on the need for appropriate nuclear security measures and on their interface with safety measures, but does not provide specific guidance on such nuclear security aspects. Additional security guidance on nuclear security is providedean be found in the IAEA's Nuclear Security Series [5, 6, 7, 8, 9].

STRUCTURE

1.14. The justification of radioisotope production facilities is <u>discussed_addressed</u> in Section 2. Designs of irradiation facilities are <u>categorized_grouped_according</u> to radiation type and methods of accessibility and shielding, as described in Section 3 of this Safety Guide. The authorization of irradiation practices, the responsibilities of the operating organization and general radiation safety issues are <u>discussed_described</u> in Section 4. <u>The_S</u>safety assessment <u>duties</u> and <u>the</u> radiation protection programme are described in Sections 5 and 6, respectively.

Formatted: Tab stops: 1 cm, List tab + Not at 0.63 cm

Formatted: Left

1.15. Section 7 provides <u>a description of recommendations on training and education_and</u> <u>training</u> of personnel of radioisotope production facilities. Section 8 deals with individual monitoring of workers of <u>radio</u>isotope production facilities. Section 9 <u>discusses provides</u> <u>recommendations on the</u> workplace monitoring._

<u>1.16.</u> Section 10 focusses on the environmental monitoring and <u>discharge of radioactive</u> effluents-discharge. Section 11 addresses the personal protective equipment being-used by the personnel. Section 12 sets out nuclear security considerations.

<u>1.17.1.14.</u> Sections 12<u>3</u> to 16 <u>provide recommendations on are devoted to the control of</u> radioactive material, facility and equipment design, testing and maintenance of the equipment, radioactive waste management, transport of radioactive material, and emergency preparedness and response, <u>respectively</u>.

1.18.1.15. Annex I sets out an eExamples of key radiation safety issues to be considered in planning the production of radioisotopes, while a safety assessment structure and an example of emergency response procedures can be found in their provided in Annexes I and Π_{z} respectively.

Formatted: Tab stops: Not at 0.63 cm

2. JUSTIFICATION OF PRACTICES

2.1. The IAEA Safety Standards Series No. SF-1. Fundamental Safety Principles [109] states that the fundamental safety objective is to protect people and the environment from harmful effects of ionizing radiation. Principle 4 on_{7} Justification of facilities and activities, states that "Facilities and activities that give rise to radiation risks must yield an overall benefit". This may be taken as equivalent to the well established principle of justification of practices, the operation of radioisotope production facilities being one example [3]. ['well-established principle of justification of practices' no longer accords with how things are worded in the current BSS]

2.2. The basic requirements for radiation protection for practices_facilities and activities established in GSR Part 3 [3] are:<u>cover</u> justification of practices_s optimization of protection and safety_ and individual dose limits-.

2.3. When the principle of justification was first formally expressed, many practices, such as the operation of radioisotope production facilities, were already in widespread use, and in general their justification was implicit. Under normal conditions, the design, construction, operation and maintenance of radioisotope production facilities result in doses to workers and the public that are a small fraction of the respective dose limits in GSR Part 3 [3]. However, Fthe operation of radioisotope production facilities can on occasion result in doses to workers and releases of radioactive material to the environment that may-might be in excess of authorized limits. Furthermore, the operation of inadequately designed facilities may-could result in dose limits being exceeded. In addition, there are other inherent radiation risks, including those associated with the security of radioactive material, the transport of radioactive material and also, ultimately, the disposal of radioactive material waste.

2.4. IAEA Safety Guide-Standards Series No. RS-G-1.9 [110] establishes the categorization system of radioactive sources based on the concept of dangerous quantities of radioactive material (D-values). The D-value is that quantity of radioactive material, which, if uncontrolled, could result in the death of an exposed individual or a permanent injury that decreases that person's quality of life [124].

2.5. Within this categorization system $[1\underline{1}\theta]$, sources in Category 1 are considered to be the most dangerous because they can pose a very high risk to human health if not managed safely

Formatted: Font: Not Italic

and securely. An exposure of only a few minutes to an unshielded Category 1 source may could be fatal. At the lower end of the categorization system, sources in Category 5 are the least dangerous; however, these sources could give rise to doses in excess of the dose limits if not properly controlled, and therefore they_need to be kept under appropriate regulatory control. The finished products of radioisotope production generally fall into source categories $3-5_{25}$ howeverThe category of such products should be considered determined in on a case by case basis for each product. [really case by case, i.e. for each product? or do you mean case by case for each facility?]

2.6. The decision as to whether the operation of <u>a</u> radioisotope production facility<u>ies</u> <u>IOK?</u> as in justification of a single facility? or of all radioisotope production facilities? BSS talks about justification of a *type of* practice] is justified is specific to the circumstances and benefits of their its use, including national priorities, so definitive recommendations regarding justification cannot be provided. Ultimately, the decision as to whether the operation of such <u>a</u> facility<u>ies</u> is justified should be made on a case by case basis by the appropriate governmental authority or authorities, <u>IOK? see footnote 20 on p35 of BSS</u> which should consider the various benefits and risks associated with their its operation in determining whether specific practices are justified. The governmental authority's decision as to whether the operation of radioisotope production facilities in the State is justified may also be made on a general basis for all radioisotope production facilities of a specific type.

Formatted: Font: Italic

3. TYPES OF RADIOISOTOPE PRODUCTION FACILITY HES

3.1. For the purposes of this Safety Guide, general <u>eategories_types</u> of radioisotope production facilit<u>yies</u> are defined on the basis of the design of the facility and the resultant radiation protection provisions necessary:

- (a) Facilities that process targets that have been irradiated by a charged particle ← beam of an accelerator to produce radioisotopes;
- (b) —Accelerator facilities with energies of less than 70 MeV/nucleon that are operated principally to produce radioisotopes. This <u>Safety Guide document</u> addresses these the following four eategories types of accelerators:
 - -(i) Low energy (<20 MeV/nucleon) cyclotrons used for medical radioisotope production;
 - <u>-(ii)</u> 20–40 MeV/nucleon <u>cyclotrons</u> used for radioisotope production cyclotrons;
 - -(iii) >40 MeV-/nucleon cyclotrons for mixedused for both research and radioisotope production; and
 - -(iv) Linear accelerators used for radioisotope production.

When recommendations in this Safety Guide only apply to specific <u>categories_types</u> of radioisotope production facilit<u>yies</u>, those <u>categories_types</u> are <u>identified_specified</u>.

Irradiation of targets in accelerators[do you need this subheading? it is the only one in this very short section]

3.3.3.2. _____-When an accelerated particle such as <u>a proton collides with the nucleus of a target</u> atom a reaction occurs forming a radioisotope product. Many <u>of the</u> radionuclides produced in accelerators cannot be produced by <u>the neutron reactions that occur in reactors</u>. The principal advantage of accelerator based radioisotope production is the higher specific activity than is the case <u>with for reactor based radionuclides</u> producedts in reactors. Accelerators are used for activation of isotopes for <u>use in research and in the production of [OK? or usage of?]</u> radiopharmaceutical<u>s usage</u>. Examples of <u>different types of accelerators</u> types I V [you don't refer to the types in this Safety Guide using this I V naming convention so could be <u>confusing</u>] can be found in <u>s</u>Section 6 of Ref. [132].

3.4.3.3. Some accelerators are designed specifically for the production of positron emission tomography (PET)-radiopharmaceuticals, e.g. ¹⁸F. Such accelerators are designed

Formatted: List Paragraph, Numbered + Level: 1 + Numbering Style: a, b, c, ... + Start at: 1 + Alignment: Left + Aligned at: 1.27 cm + Indent at: 1.9 cm

Formatted: Bulleted + Level: 3 + Aligned at: 3.17 cm + Indent at: 3.81 cm

Formatted: Tab stops: 1 cm, List tab + Not at 0.63 cm

and sold tofor use in radio isotope production facilities or hospitals. To produce ¹⁸F, the target is irradiated and the liquid mixture (¹⁸O-water containing ¹⁸F) is transferred in capillary pipes to a processing hot_-cell.

3.5.3.4. Accelerators for the production of radioisotopes are generally located in the same building as wherein which the -radioisotopes containing products are synthesized.are processed into radioactive products for subsequent use. [OK? same language as in SCOPE]

8

4. DUTIES AND RESPONSIBILITIES

GENERAL

4.1. IAEA Safety Standards Series No. GSR Part 1, Governmental, Legal and Regulatory-Framework for Safety [14] establishes requirements for the governmental, legal and regulatory infrastructure for safety of facilities and activities, including those associated with radioisotope production facilities, and attributes duties and responsibilities to all relevant parties. GSR Part 3 [3] provides the general framework for these duties and responsibilities, and this Section provides further guidance in the context of radioisotope production facilities.[Hari I think you need to say something about responsibilities for the govt or RB. You could quote from GSR Part 3 extensively, as in DS491/DS420, or maybe this is enough??]

4.1.4.2. The person oroperating organization responsible for the radioisotope production facilityies and activities that give rise to radiation risks should have has the prime responsibility for protection and safety. Other parties should also [it's not a should see para 3.5 of SF 1] have specified responsibilities for with regard to protection and safety. In line accordance with para. 3.6 of the IAEA Fundamental Safety PrinciplesSF-1 [109], the operating organization is responsible for:

- (a) "Establishing and maintaining the necessary competences;
- (b) Providing adequate training and information;
- (c) Establishing procedures and arrangements to maintain safety under all conditions;
- (d) Verifying appropriate design and the adequate quality of facilities and activities and of their associated equipment;
- (e) Ensuring the safe control of all radioactive material that is used, produced, stored or transported;
- (f) Ensuring the safe control of all radioactive waste that is generated: and."

(f)4.3. [jt would be interesting to talk about who the operating organization (typically) is for radioisotope production facilities located within hospitals, for example, so that responsibilities can be appropriately located; DS419 has an extensive discussion about the well logging company and the client; For a radioisotope production facility located within a

Formatted: Left

Formatted: List Paragraph, Indent: Before: 0 cm, First line: 0 cm, Line spacing: 1.5 lines, Tab stops: 1 cm, List tab + Not at 1.63 cm

Formatted: English (United States)

Formatted: Indent: Before: 0 cm, First line: 0 cm, Don't add space between paragraphs of the same style, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 1 cm + Tab after: 1.63 cm + Indent at: 1.63 cm, Allow hanging punctuation, Font Alignment: Auto, Tab stops: 1 cm, List tab + Not at 1.63 cm Formatted: Highlight hospital, the operating organization for the hospital has the prime responsibility for safety.something similar is going on here and I do believe it needs to be addressed clearly] (g)4.4. The operating organization is also responsible for Eestablishing plans and procedures to respond to any nuclear or [there is no defined term 'radiological emergency' so I prefer to use the defined term] radiological emergency that may arise at the facility and for coordinating exercises to test the same such plans and procedures [3, 153].

4.2.4.5. Specific responsibilities for the design, operation and eventual decommissioning of the facility will, however, be assigned to <u>all-individuals and groups at a range</u> of hierarchical levels within the designer, constructor and operating organization, including senior management, the radiation protection officer-(RPO), workers who operate the facility and handle radioactive material, and qualified experts or /radiation protection advisers (RPAs).

MANAGEMENT OF RADIATION SAFETY AND SAFETY CULTURE

4.3.4.6. The operating organization, through its managers, is responsible for the
establishment and implementation of the technical and organizational measures necessary to
ensure protection and safety and for compliance with the relevant legal and regulatory
requirements. If this expertisze is not available in-house, an external qualified expert_or
Aradiation protection adviser RPA should be appointed to provide advice regarding radiation
safety and regulatory compliance with regulatory requirements.

4.4.4.7. Responsibility for overseeing radiation safety, and verifying that all activities involving radioactive material are carried out in accordance with regulatory requirements may be delegated to a senior manager. Other Rresponsibilities for in relation to radiation safety are required to be established assigned within the operating organization [OK? or are you talking about other parties' responsibilities, as in BSS para 2.41?], and they should be agreed to by all relevant parties individuals [22] and recorded in written formwriting. Procedures The operating organization is required to set up and implement the technical and organizational measures necessary should be put in place [I think this is too important to paraphrase write as a should or do you mean something significantly different?] for the protection of workers, the public and the environment, and for ensuring to ensure that doses are kept as low as reasonably achievable (the principle of optimization of protection and safety). All policies and procedures should are required to be documented [3] [OK? this looks like BSS para 3.94(a)], and should be made available to all staff and the regulatory body as appropriate.

Formatted: English (United States) Formatted: English (United States) Formatted: Indent: Before: 0 cm, First line: 0 cm, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 1 cm + Tab after: 1.63 cm + Indent at: 1.63 cm, Allow hanging punctuation, Font Alignment: Auto, Tab stops: 1 cm, List tab Formatted: English (United States) Formatted: English (United States)

Formatted: Heading 2 Formatted: Font: Bold

Formatted: Highlight

Formatted: Highlight

4.5.4.8. Managers are required to foster and sustain a strong strong [Peter Tarren wanted to change this to 'effective' but Requirement 12 of GSR Part 2 says 'strong'] safety culture within their organization, to encourage a questioning and learning attitude to protection and safety at all levels in the organization, and to discourage complacency with regard to safety [164]. A strong and effective [I put the 'effective' bit in here instead] safety culture is promoted by management arrangements and workers' attitudes, which interact to foster a safe approach to the performance of work. Safety culture is not confined to radiation protection; it should also extend to conventional safety.

4.6.4.9. In cases where there is a potential conflict between operational responsibilities, such as responsibilities for meeting a production schedule, and responsibilities for radiation safety, as an overriding priority the protection and safety issues should receive the attention warranted by <u>its-their</u> significance.

4.7.4.10. In order to foster and sustain a strong safety culture, management of the Ooperating organizations [the operating organization cannot consider/learn/foster/seek, etc. It has to be management or individuals within the OO] with a strong safety culture should consider all the circumstances when in which incidents could occur[I think they should consider up front, *before* the incidents, right?]; they all individuals within the operating organization should strive to learn from their mistakes, foster-maintain a questioning attitude and seek continuous improvement in the safety of work processes. For eachIf an incident occurs, the question of acceptabilitye of behavior should be mswered on a case by case basisaddressed and, in some cases, disciplinary measures may be takenappropriate.

4.8.4.11. As stated in GSR Part 2 [164], the operating organization is required to establish, implementapply, sustainassess and continually continuously improve an integrated management system to ensure safety.[we need to stick closer to wording of Req 3 of GSR Part 2] This integrated management systemthat should definesspecify the responsibilities of all relevant persons and that details set out the key radiological radiation protection and safety requirements for personnel, equipment and the facility. The management system should be based on national or international standards [14, 15, 16, 17, 18]. It should incorporate mechanisms for routine internal inspections and audits, as well as third party audits, as appropriate. The radiation protection programme should be a part of the integrated management system.

Facilities and resources

Formatted: Font: Italic

4.9.4.12. The operating organization should-is required to ensure that suitable-appropriate equipment and safety systems have been installedare provided and equipment is available to enable work to be carried out safely and in accordance with regulatory requirements [3].[this seems like BSS para 2.52(b) to me]

Notification and authorization

4.10.4.13. An application for a licenseauthorization [pls check elsewhere you don't use licence what is the usual term for these facilities?] should contain information that demonstrates the safety of the practice. Guidance relating toRecommendations on the preparation of an application for the authorization of a radioisotope production facility, and its subsequent review by the regulatory body, is are included provided in a IAEA Safety Standards Series No. GS-G-1.5GSG-13, Functions and Processes of the Regulatory Body for Safety [197].

4.11.4.14. When applying for an authorization, the operating organization should-is required to provide the regulatory body with the appropriate documentary evidence to demonstrate that an adequate level of radiation safety will be afforded and maintained [3]. [OK as a requirement? this seems to be BSS para 3.9(a) and (c) mixed]

4.12.4.15. The documentary evidence necessary to support an authorization request should include, as a minimum, specific information concerning the <u>following</u>:

- (a) Identification of the operating organization and the individual(s) representing the operating organization;
- (b) <u>The Rradioisotopes and the chemical forms of the material to be possessed processed [?]</u> and stored;
- (c) <u>The C</u>characteristics of the particle accelerator, i.e. <u>its</u> type (cyclotron, <u>or</u> linear accelerator), energy, current, beam characteristics and layout, including <u>its</u> size and /geometry;
- (d) <u>The Ffacility in which the particle accelerators will be located and/or the radioactive material will be processed and stored, with including particular specific attention paid toinformation on the associated safety systems and equipment, e.g., radiation shielding, interlock systems, fume hoods, remote handling tools, effluent exhaust systems,</u>

monitoring systems, and warning systems, and their appropriate <u>positions-locations</u> in the <u>layoutfacility [?];</u>

- (e) <u>The Ll</u>ocations where <u>the particle accelerators</u> will be operated and radioactive material will be processed and stored;
- (f) -<u>Means of Vv</u>erification that the recipient has an authorization to receive <u>any</u> radioactive material being transferred <u>out of the facility</u>;<u>FOK? I don't think the applicant can yet</u> provide the verification, only the means of verification]
- (g) <u>The Fi</u>nventory system to be used to account for radioactive material;
- (h) Identification and details of qualifications of the radiation protection officer (RPO) and, where appropriate, qualified experts or radiation protection advisers (RPAs);
- (i) <u>The Oo</u>perating organization's requirements for the training and qualification of all relevant staff;
- (j) <u>Information supporting the Justification for the operation of the facility; [OK? does the applicant justify the facility?]</u>
- (k) <u>The Ssafety assessment covering the operation of the facility;</u>
- (l) <u>The Rr</u>adiation protection programme;
- (m) Arrangements for the management of radioactive waste; and
- (n) Arrangements for responding to a <u>nuclear or</u> radiological emergency within the facility premises (see Section 16);
- (o) <u>The Finitial decommissioning plan and financial assurance</u>.

4.13.4.16. The operating organization should obtain the approval of the regulatory body before commencing <u>construction of [OK? or operation of?]</u> a new facility or implementing modifications to the facility. The operating organization should notify the regulatory body of any changes to key personnel, in particular senior managers and the principal radiation protection officer.

RADIATION PROTECTION OFFICER

Formatted: Left

4.14.4.17. The operating organization should is required to appoint at least one employee as a radiation protection officer (RPO)-to oversee the day to day implementation of the radiation protection programme and to carry out the duties required by the programme_[3]. While Although the radiation protection officer RPO-oversees the application of the safety standards, the prime responsibility for safety remains with the operating organization. The radiation protection officer RPO-should be technically competent in radiation protection matters of relevance for a-the given type of radioisotope production facility. The radiation protection officer RPO-should report directly to senior management and should have sufficient authority to discharge his or the duties. Where there is a conflict between safety and operations, the The radiation protection officer RPO-should have the authority to intervene to stop an unsafe or non-compliant activitywork that is at risk.

4.15.4.18. During times when the <u>radiation protection officer RPO</u> is not available to provide oversight on radiation safety matters, such as during periods of absence from the facility, arrangements should be made for the prompt provision of authoritative advice concerning radiation safety matters. Such arrangements could include timely access to qualified experts/RPAs or radiation protection advisers or the designation of deputy <u>radiation</u> protection officers <u>RPOs</u> who are present at the facility during times of operation.

4.16.4.19. The responsibilities of the <u>radiation protection officer RPO</u> should include the following, some of which may require consultation with, or assistance from, a qualified expert:

- (a) Oversight of facility operations to assist the operating organization to in complying with regulatory requirements;
- (b) -Oversight of the review of the shielding design and <u>of statements records [OK?]</u> regarding occupancy and workload;
- (c) Optimizing exposure controls and maintaining safety systems and other equipment that contributes to controlling exposure of workers and members of the public;
- (d) Oversight of the inspection and maintenance of safety systems, personal protective equipment, radiation monitoring equipment and warning <u>features_systems</u>;
- (e) Establishment of controlled areas and supervised areas and oversight of access control for controlled areas;

- (f) Periodic review of arrangements for individual monitoring of workers;
- (g) Investigation of high, unexpected or reportable exposures and overexposures;
- (h) Ensuring that workers are suitably trained in the use of equipment and in radiation protection, and that they receive regular refresher training;
- Ensuring that emergency plans and procedures are established and maintained and <u>that</u> exercises are conducted as appropriate (see Section 16);
- Oversight of arrangements for environmental monitoring, including review of the results of such monitoring;
- (k) Establishment, issue and periodic review of local rules (including work permits where appropriate);
- (l) Investigation and reporting of incidents <u>and including</u> accidents;
- (m) Liaising with contractors, designers and suppliers with regard to radiation protection matters and significant changes to physical or operational aspects of the facility;
- Ensuring the adequacy of safety assessments and emergency plans for any reasonably foreseeable incidents with consequences for radiation protection;
- (o) Oversight of issues relatinged to the safe transport of sources, including the receipt of packages containing radioactive material and the preparation of packages for shipment¹/₂, and
- (p) Maintaining records relevant to the radiation protection programme, including records concerning the radioactive material inventory, <u>records of occupational exposure from</u> workplace monitoring and, individual monitoring, <u>records of environmental monitoring</u> and <u>records relating to radioactive waste management-[? disposal?]</u>.

QUALIFIED EXPERTS AND ARADIATION PROTECTION ADVISERS

4.17.4.20. A qualified expert <u>RPA_or radiation protection adviser</u> is an individual who-is duly recognized, by virtue of certification by appropriate boards or societies, professional licenceses or academic qualifications and experience, is duly recognized as having expertise in a relevant field of specialization. The qualifications of a qualified expert are described in

Formatted: Left

paras 3.65 3.71 [delete because GSG-7 is not yet edited para numbers might change] of Ref.[AEA Safety Standards Series No. GSG-7, Occupational Radiation Protection [2018].

4.18.4.21. The operating organization may identify one or more qualified experts/RPA_or radiation protection advisers to provide advice on various matters concerning radiation safety in the design and operation of the facility. A qualified expert/RPA_or radiation protection adviser need not be a full time employee of the operating organization but could be employed on a part-time or an ad hoc basis. Regardless, arrangements should be made for the advice of a qualified expert/RPA_or radiation protection adviser to be available when necessary. As with the radiation protection officerRPO, the operating organization cannot delegate its responsibility for safety to a qualified expert.

4.19.4.22. <u>A-The qualified expert/RPA or radiation protection adviser</u> should be experienced in radiation protection matters and should have had:

- (a) <u>Have had</u> <u>theoretical training that includes training in radiation protection and the properties of the radiation as used present in the radioisotope production facility;
 </u>
- (b) <u>Have Aa</u> thorough knowledge of the hazards associated with the radiation and other potential hazards present and the ways in which the hazards can be controlled and minimized;
- (c) <u>Have A-knowledge of the emergency preparedness category of the facility in the context of the emergency preparedness and response (EPR)-plans conforming to in accordance with the relevant requirements of the international standards [153];</u>
- (d) <u>Have an An-</u>understanding and detailed knowledge of the working practices <u>used inin</u> the facility, as well as general knowledge of the working practices in other similar facilities;
- (e) <u>Have a A-</u>detailed working knowledge of all regulatory provisions, relevant codes of practice and protection standards, guidance material and other information necessary for giving advice in connection with the work with radiation undertaken <u>in the radioisotope</u> <u>production facilityby the operating organization</u>;

- (f) <u>Have an An</u>-awareness of regulatory requirements that could affect the work with radiation on which the qualified expert/<u>RPA_or radiation protection adviser</u> gives advice;
- (g) <u>Have</u> <u>F</u>the ability to give advice so that the operating organization can comply with regulatory requirements and follow good <u>practices in relation to</u> radiation protection <u>practices</u>;
- (h) <u>Have</u> <u>Fi</u>he personal qualities to be able to communicate <u>effectively</u> with workers and their representatives;
- (i) <u>Have</u> <u>+</u>the ability to keep up-_to-_date with developments in the use of radiation in the field in which the qualified expert<u>RPA- or radiation protection adviser gives advice and with developments in radiation protection in general.</u>

4.20.4.23. The operating organization should provide the qualified expert/RPA or radiation protection adviser with adequate information and resources as may be necessary for the expert to work effectively. The information should include a clear statement of the scope of the advice that the expert is expected to give.

4.21.4.24. The operating organization may consult the qualified expert<u>or</u> radiation protection adviser/RPA on a wide range of issues relating to radiation safety, including:

(a) Optimization of protection and safety;

- (b) Maintenance of engineering features and other equipment;
- (c) Workplace monitoring, individual monitoring and environmental radiation-monitoring;
- (d) Investigation of high exposures and overexposures;
- (e) Staff training;
- (f) Safety assessment and emergency arrangements³;

³ In line with Ref. [13], eEmergency arrangements are "the integrated set of infrastructural elements, put in place at the preparedness stage, that are necessary to provide the capability for performing a specified function or task required in response to a nuclear or radiological emergency" [14]. These elementsand- may include: assignment of [see actual definition in GSR Part 7]-authorities and responsibilities, organization, coordination, personnel, plans, procedures, facilities, equipment or, training, exercises, quality management programme etc.

- (g) Examination of any plans for a <u>new [OK? what is the meaning otherwise?]</u> facility or for modifications of an existing facility;
- (h) Independent audits relatinged to radiation safety matters;

(i) Quality management;

- (j) Emergency preparedness and response (see Section 16); and
- (k) -Radioactive waste management.

WORKERS

4.22.4.25. While the primary-prime responsibility for radiation-safety lies with the operating organization, workers (including assistants and trainees) have a responsibility to work safely and to take all reasonable actions to restrict their own exposure and those of other workers and members of the public. Workers include individuals whose work involves exposure to radiation or work activities that could result in exposures to-of other individuals, or the environment [these are not examples of the environment] such as process operators, operators working with product shipments, operators working with waste, research scientists, pharmacists, laboratory technicians, personnel with housekeeping duties and personnel who perform routine maintenance activities. The competence of these-workers to perform their duties in a safe manner should be verified by thee radiation protection officerRPO. In order to meet Requirement 22 of GSR Part 3 [3], Ww orkers should:

- (a) Should Ffollow the local rules (see para, 4.267) and any relevant procedures;
- (b) <u>Should w</u>Wear their individual dosimeters in the correct place at all times during radiation work and record their daily doses. If the dose exceed<u>sed</u> the level set by the local rules they should report it to the responsible (senior) manager or <u>the radiation</u> <u>protection officer RPO</u> (see Section 6);
- (c) <u>Should u</u>Use radiation monitors properly and in a systematic manner (see Section 8);
- (d) <u>Should c</u>Cooperate with the <u>radiation protection officer</u> <u>RPO</u>-and qualified experts on all radiation safety issues;
- (e) <u>Should p</u>Participate in any training concerning radiation safety₁ including emergency drills and exercises;

Formatted: Left

- (f) <u>Should aAbstain from any willful action that could put themselves or others in contravention of regulatory requirements or of the operating organization's own requirements[ocal rules;[OK?] [this is very similar to GSR part 3 para 3.83(e)]</u>
- (g) <u>Should -contribute to Bbuilding</u> a safety culture.<u>[change here from P. Tarren's comment</u> to consider workers' role, safety culture starts at top]

4.23.4.26. Workers should promptly inform the <u>radiation protection officer RPO</u> of any event or circumstances that could adversely affect protection and safety and/or result in radiation doses that exceeds the organization's dose investigation level to any persons. These <u>Such</u> events could include failures or observed deficiencies in safety systems and warning systems, errors in following procedures, or inappropriate behaviour. A written report should be made to the <u>radiation protection officer RPO</u> as soon as practicable after the event or observation.

4.24.4.27. Radiation safety should be incorporated into the daily routine of work by all personnel.

4.25.4.28. Temporary workers should comply with <u>the</u> work practices and local rules within <u>of</u> the facility.

LOCAL RULES AND PROCEDURES

4.26.4.29. The operating organization should ensure that local rules and procedures for protection and safety are fully understood by the workers. Local rules and procedures—and should, as a minimum, include the following (see also GSG-7 [1820], paras 3.87–3.92):

- (a) A description of the nature of the hazards posed by the facility and the safety features used to minimize the risks $\pm \hat{z}$
- (b) Written emergency plans, procedures and instructions in line with their respective duties (see Section 16).
- (c) A description of the functions, duties and responsibilities of key individuals within the operating organization with regard to radiation safety, including the qualified expert <u>RPA or radiation protection adviser</u> and the radiation protection officer<u>RPO</u>;
- (d) The <u>method</u> of ensuring that persons entering controlled areas are wearing appropriate radiation monitoring devices and that the results of the monitoring are recorded.⁺

Formatted: Not Highlight

Formatted: Not Highlight

Formatted: Left

- (e) Access and egress monitoring procedures for workers and visitors.
- (f) Written instructions covering actions to be taken in the event of malfunctions. These instructions should identify individuals to be notified in the event of a malfunction and should provide a general outline of the corrective actions to be taken.¹
- (g) Written instructions to ensure that the facility is maintained as prescribed in <u>the</u> design documentation.
- (g)(h)Written instructions to require that the workers call for assistance from the radiation protection officer RPO-when a hot cell or particle accelerator shielding is to be [?] opened.;
- (h)(i) Written instructions describing the wearing of suitable personal protective clothing in supervised and controlled areas;
- (i)(j) Written instructions to require that the workers check with the <u>radiation protection</u> officer RPO-that the facility is safe before <u>entranceentering</u>.

5. SAFETY ASSESSMENT

		Formattada Loft
	GENERAL	Formatted: Left
	2.0. General safety requirements on for safety assessment for facilities and activities are-	Formatted: Indent: Before: 0 cm, Tab stops: Not at 1.59 cm
	provided byestablished in IAEA Safety Standards Series No. GSR Part 4 (Rev. 1), Safety	
	Assessment for Facilities and Activities [1921]. which includes the necessary arrangements	
	for:	
(c)	-scope, purpose, and responsibilities (overall requirements 2–4),	Formatted: Indent: Before: -1 cm
(d)	- specific requirements (5–12),	
(e) -	defence in depth and safety margins (requirement 13),	
(f)	safety analysis (requirements 14–19),	
	(g) DOCUMENTATION, INDEPENDENT VERIFICATION, MANAGEMENT, USE	Formatted: Heading 2, Left, Space Before: 0 pt, After: 0 pt, Line spacing: 1.5 lines, No bullets or numbering
	AND MAINTENANCE (REQUIREMENTS 20-24). [THIS IS TOO MUCH INFO, NOT-	
	NORMAL STYLE TO EXPLAIN WHAT ANOTHER BOOK CONTAINS IN SUCH	
	DETAIL PLS CONSIDER DELETING	
	5.1. This section provides recommendations on meeting the rRequirements of GSR Part 4	
	(Rev. 1) [1921] mentioned above in para. 5.1 and Requirement 13 of GSR Part 3 [3] on	
	safety assessment in GSR Part 3 [3] are addressed in this Section in respect of radioisotope	
	production facilities.	
	PURPOSE AND DEVELOPMENT PROCEDURE	Formatted: Heading 2, Left, Space Before: 0 pt, After: 0 pt
	5.2. Requirement 4 (Purpose of the safety assessment) of GSR Part 4 (Rev. 1) [1921]	
	requires states that the primary purposes of the safety assessment of OSR Fait 4 (Rev. 1) [1721]	
	an adequate level of safety has been achieved for a facility or activity, and whether the basic	
	safety objectives and safety criteria established by the designer, the operating organization	
	and the regulatory body, in compliance with the requirements for protection and safety as	
	established in [GSR Part 3 [3]], have been fulfilled".	
	established in FORK Full 5 [5]], have been fullined	
	RESPONSIBILITY FOR <u>DEVELOPMENT OF THE</u> SAFETY ASSESSMENT	Formatted: Heading 2, Left, Space Before: 0 pt, After: 0 pt
	DEVELOPMENT	
	5.3. In accordance with Requirement 13 of GSR Part 3 [3] and with Requirement 3 of GSR	
	Part 4 (Rev. 1) [21] states that the person orthe operating organization , or registrants and	
	21	
	21	

licensees, as appropriate, is required to conduct a safety assessment that, depending on the type of practice or source, is either generic or specific to the practice or source for which they are responsible.

5.4. The preparation for the safety assessment, in terms of assembling the expertise, tools and information required to carry out the work₁ is addressed in <u>R</u>+equirement 5 of GSR Part 4 (Rev. 1) with <u>a</u>-detailed <u>description-requirements established</u> in paras 4.18 (a)–(d) <u>of GSR</u> Part 4 (Rev. 1) [4921].

5.5. The operating organization of the radioisotope production facility should be responsible for the fulfilment of requirements mentioned above in paras 5.4–5.5 [3, 19].[info moved up into para 5.2]

5.6.5.5. An example schematic <u>A diagram</u> of a safety assessment for a radioisotope production facility is <u>illustrated shown</u> in Fig<u>ure</u> 1. This figure outlines the key aspects of the radioisotope production facility <u>which that</u> should be addressed in a safety assessment. Thereafter, each of tThe individual risk assessments (e.g. <u>assessments regarding</u> shielding, emissions, engineering controls <u>and</u>, decommissioning, etc.) should be collated into a safety assessment report for the facility. The same approach should be adopted whether <u>it-the safety assessment</u> is for a new standalone facility or a modification to an existing and approved facility. Some specific examples of safety <u>requirements arrangements</u> (e.g. <u>for</u> shielding, interlocks, transfer lines, remote handling, fume hood <u>and</u>, ventilation <u>etc.</u>) are provided in paras 5.13–5.45.




FIG. 1. Example schematic Diagram-of a safety assessment for a radioisotope production facility

5.7.5.6. Requirement 6 of GSR Part 4 (Rev. 1) [<u>1921</u>] <u>states_requires_that</u> the possible radiation risks associated with the facility or activity <u>shall</u> be identified and assessed. An example schematic of the The key <u>areas of radiological_radiation</u> risks associated with a radioisotope production facility <u>is are presented shown</u> in Fig<u>ure 2</u>.




FIG. 2. Key areas of radiological-radiation risks associated with the a radioisotope production facility.

5.8.5.7. During and post irradiation, there is a risk of volatile radioactive products being released to the environment; this may occur while the product is being transferred to the hot cell.

5.9.5.8. During synthesis in the hot cell, there is a potential-risk [the word risk already contains the notion of potential] of radioactive contamination of the environment outside and inside the building, which could potentially result in potential exposure [potential exposure is not exposure] of operational staffworkers and a limited number of the members of the public in the local vicinity. This risk is directly related to the potential presence of volatile products within the hot cell during radiosynthesis. The risk of this such contamination should be minimized by an appropriate negative pressure regime in the hot cell. The risk of a radiological release to the atmosphere should be controlled by the appropriate engineering

controls (e.g. filtration, <u>use of a motorized damper [P. Tarren asked why does this control the risk? is it OK to leave it or should it be removed?] and an₂ abatement system, etc.).</u>

5.10.5.9. During filling of the finished product in the dispenser hot cell, the appropriate engineering controls should be in place (i.e. good medical practices (GMP) or other aseptie standards for aseptic manufacturing-[OK?]) to ensure that the operator workers and the product are protected and products are safe. [what does it mean to protect the product? shield?] Specifically, it is important that any potential any volatile radioactive material in the synthesis hot cell should be prevented from entering the dispensing hot cell. This can be achieved by using the appropriate pressure regime or other options (e.g. ensuring flow remains laminar flow [change made on the basis of P Tarren's query of why this controls risk] and, filtration). It is important to note that the In dispensing of the finished product for use in humans, should be complied with; which this may include dispensing in positive pressure regimes.⁴[moved to main text because no shoulds in footnotes; footnote deleted]

5.11.- The facility operating organization should verify that the recipient has a permit or authorize attor to receive the radioactive material being transferred out of the facility.

5.12.5.10. Transport of the finished products in the shielded containers should comply with the IAEA Transport Regulations [220] or equivalent national regulations -inside the State. If merged the two very short paras covering transfer/transport}

5.13.5.11. There are also risks during the maintenance of accelerators and adequate consideration should be given to protection and safety considerations should be given when maintenance works is are undertaken. For example, The physico-chemical nature of the contaminants, and the presence of activated products coming from the targets, radionuclides with longer half-lives and, melted_pieces of equipment_ete may vary_differ in-during_such situations maintenance compared to normal operation. [pls-check __list seems a bit fuzzy]

SAFETY ARRANGEMENTS

Formatted: Indent: Before: 0 cm, Tab stops: Not at 1.59 cm

Formatted: Heading 2, Left

Formatted: Highlight

⁴-It is important to note that the dispensing of the finished product for use in humans should comply to local GMP requirements, which may include dispensing in positive pressure regimes.

Shielding

5.14.5.12. Direct radiation exposure of workers and members of the public due to the operation of the radioisotope production facilityies should be attenuated to optimized levels by the use of appropriate shielding. Concrete is often used to construct the accelerator room shielding, but other materials such as earth fill, steel and lead may are [OK? is this a statement or permission or a statement of fact?] also be used in its construction. The shielding properties of particular materials are well established $[2\underline{31} - \underline{2308}]$, but and experience deriving from existing radioisotope production facilities should be taken into account in designing the appropriate shielding. Adequate consideration should be given for to shielding neutrons that could be generated in accelerator facilities, for example by usinguse of boronated [Google prefers 'borated concrete' to 'boronated concrete'; OK?] concrete for the shielding material. The shielding should provide adequate reductions in radiation levels to keep doses within the dose constraints established or agreed to by the regulatory body.

5.15.5.13. Penetrations of the shielding are necessary for entry and exit ports for personnel and products and for the ventilation system and other ducting. These penetrations can potentially create particular problems challenges for the design of the shielding designer, and itwho should be ensured that there is no direct radiation leakage path, and should ensure that the use of maze entrances and shield plugs are-is sufficient to reduce external radiation fields to optimized levels. Care should be taken to ensure that all significant radiation paths are fully shielded. Considerations should also be given on-to_the possible skyshine effect—while designing the shielding of the facility. Where practical, all tubes, pipes and conduits should take a curved or stepped path through the shielding material to reduce external radiation levels or should be embedded in the concrete slab using pits and trenches.

5.16.5.14. Secondary neutrons generated during radioisotope production give rise to neutron activation of the cyclotron⁴ or linear accelerator components and vault room wall. Additional forms of shielding may be required to attenuate and shield the neutrons. Activation of the shielding material may pose additional risks while-for decommissioning of the facility.

5.17. Once the shielding has been designed, no subsequent changes should be made, unless they have been carefully considered and agreed with the regulatory body.

5.15. Remote handling tongs, master/slave manipulators<u>[can we drop this not very nice</u> phrase? or replace with 'robotic manipulators'?] Formatted: Default, Indent: Before: 0 cm, Space Before: 12 pt, After: 6 pt, Line spacing: 1.5 lines, Outline numbered + Level: 2 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0.95 cm + Tab after: 1.59 cm + Indent at: 0.95 cm, Tab stops: 1 cm, List tab + Not at 1.59 5.18.5.16. <u>Handling of R</u>radioactive materials in the hot cells <u>should be handled using may</u> require <u>involve the use of a remote handling tools</u>, such as tongs or robotic manipulators, if the chemical processing system is not fully automated. <u>Ino should statement in here?</u>]

Inner surfaces of hot cells

5.19.5.17. The inside of the-a hot cell should have a leak tightan air tight liner that can provide air tightness to prevent the release of radioactive materials from the hot cells. It-The liner should also be suitable for the process that takes place inside of the hot_-cell (e.g. the liner should have an acid fume resistant coatings in solid target dissolution stations where hot acid can be present). The eEdges of the liner should be rounded with an appropriate radius to prevent the accumulation of contaminated dust. The surface should not have unnecessary protrudinged parts for easy decontamination of the surface. The liner itself should have enough mechanical strength to support any heavy system intended to be installed. For the production of radiopharmaceuticals, the inner liner should be designed to comply with the air classification-guality [OK? air classification is not usually used in the standards; seems very specific to leave with no explanation] and air flow requirements (e.g. demands for a laminar flow to remain laminar when filling machines or /dispensing systems are used for handling open radiopharmaceuticals).

Fume hoods

<u>5.20.5.18.</u> Fume hoods are appropriate for the handling of hazardous and radioactive materials when the potential for <u>airborne</u> contamination <u>control [OK?otherwise I don't</u> <u>understand the sentence _pls check]</u> is low high and when external dose rates are low. Partial-enclosure fume hoods allow <u>high-good</u> accessibility by chemists and manipulation of special equipment, while affording protection from chemical fumes and radioactive aerosols. The sash height should be adjusted to maintain the face velocity (0.4 to 0.6 m s⁻⁴) of air entering the hood opening, which should be greater than the capture velocity of contaminants likely to be released into the fume hood work area to prevent releases into the general laboratory area.⁵

5.21.5.19. Fume hoods may require external shielding depending on the dose rate <u>fis dose</u> rate OK? who is getting a dose? maybe 'activity'?] of associated with the intended operation.

⁵ A typical face velocity is around 0.4 to 0.6 m s⁻¹.

5.22.5.20. <u>The iInspection and /maintenance of the fume hood should be done-performed on</u> a scheduled frequency. The face velocity should be checked prior to use.⁶

<u>5.23.5.21.</u> The exhaust air should be monitored <u>based on the concentration of the for</u> effluents. The volume of exhaust air can be determined if the face velocity and sash area is are known. The exhaust air should be routed through an appropriate filtration system to limit releases of radioactive material to <u>the external environments</u>.

Glove boxGloveboxes

5.24.5.22. <u>Glove boxGlovebox</u>es are air_-containment systems that isolate the hazardous or radioactive materials from the operator's laboratory environment. <u>Glove boxGlovebox</u>es can be used for non-gamma emitting radioisotopes where the shielding of the hot cell is not requirednecessary [OK?].

5.25.5.23. <u>Glove boxGlovebox</u>es are constructed <u>using_from</u> mild steel, stainless steel_₅-or aluminium<u>, with coated on</u> the interior surfaces <u>coated</u> with chemical-resistant epoxy paint, <u>[OK? or is it the metal that is 'coated on the interior surfaces'?]</u> laminated safety glass panels for viewing work activities inside the box, and heavy neoprene gloves (<u>in the [OK?]</u> glove port) that allow the operator to handle materials safely inside the <u>glove boxglovebox</u>. Glove <u>boxGlovebox</u>es should be equipped with adequate lighting. <u>Glove boxGlovebox</u>es should be maintained periodically and <u>checks made on</u> their integrity <u>checked</u> (for leaks<u>and</u>; damage <u>etc</u>).

Clean environment considerations

5.26.5.24. In order to maintain a clean environment <u>for-in</u> the <u>radioisotope</u> production facility, the production line should be in a clean room or isolator to ensure the required air classification-quality is achieved. If cleaning agents are used to achieve a sterile <u>or</u> aseptic environment in the hot cell (e.g. H₂O₂), a risk assessment should be carried out to ensure that <u>it does the use of such agents</u> not adversely affect the <u>extraction</u>-filtration system.

Interlocks

⁶ Fume hoods require need a large volume of air and this may have design implications <u>on-for</u> the volume of air required needed in the <u>radioisotope</u> production facility.

5.27.5.25. A_robust interlock that cannot easily be defeated should be installed at the access door to controlled areas such as cyclotron<u>or</u>/linear accelerator rooms and target rooms, to protect the workers from ionizing radiation. Specialist advice on the suitability of interlocks should be sought.

5.28.5.26. Access by personnel to the elevated radiation field following an-irradiation, securing of the radiation room prior to initiating irradiation, and irradiation start procedures should incorporate a series of sequential safety interlocks and controls. Such safety interlocks and controls should be so-designed such that any attempt to pre-empt the controls or to apply them out of sequence will automatically prevent the intended operation.

Transfer systems

5.29.5.27. Transfer systems for the radioactive materials vary <u>differ</u> depending on what types of materials are <u>being</u> transferred.

5.30.5.28. Transferring of radioisotopes from the cyclotron or rlinear accelerator to the hot cell is achieved by using shielded transfer lines and inert gases to move the product from the target to the hot cell.

5.31.5.29. Transferring of the radioactive materials between hot cells can be done either through a simple shield door and/or a pass box installed between hot cells. Also, aA conveyor can also be employed to transfer the radioactive materials. In cases of a liquid, Liquids it can be delivered through the tubing either by vacuum or pressure. Delivery of gases can also be done by using a method similar to that for liquid. Specially, the In particular, gas transfer should be done in a closed system to ensure that there is no risk of a radioactive release of radioactive to the environment.

5.32.5.30. Transferring of target materials from the target room to the processing hot cells is similar to the transfer of radioactive gases and liquids. However, the transfer of solid targets requires necessitates more physical and robust transfer systems that are more robust feorreet meaning?], utilising and which utilize pneumatic systems as opposed to inert gases.

5.33.5.31. Transport of a bulk <u>sourceamounts of radioactive material</u>, dispensed vials, and sealed sources to outside of the building should follow the protocols for the transport of radioactive material described in <u>sS</u>ection 15.

Ventilation and other systems [?]

5.34.5.32. For <u>a radioisotope production facility</u> within <u>a</u> larger organizations (for example, <u>a radioisotope</u> production <u>facility</u> siteds within a hospital environment), systems and 4 procedures should be put in place to ensure that no personnel can access the ventilation system or power distribution cabinet<u>unit</u> [why the power distribution cabinet in this section <u>on ventilation?</u>] of the facility without prior information and consent of the facility management and the <u>radiation protection officerRPO</u>. The operating organizsation needs to should enforce appropriate standard operating procedures (SOPs) for the maintenance of all shared and interfacing infrastructure.[why shared infrastructure in this section?]

5.35.5.33. Air pressure within the radioisotope production facilit<u>yies</u> should generally be kept lower than the external air pressure at all times so that air flows from outside the facility to the inside. Any air that leaves the building should pass through ducting equipped with filtration and monitoring equipment. Appropriate filters should be used depending upon the chemical compounds or radioisotopes produced.

5.36.5.34. Redundancy of eritical essential ventilation systems should be in placeprovided to:

- (i) <u>To Ee</u>nsure the safety of the site during <u>ventilation</u>-maintenance<u> of the ventilation</u> <u>system:</u>-
- (ii) <u>To Ee</u>nsure back-up power for <u>eritical-essential</u> [OK? can we avoid 'eritical' to avoid any confusion with a buildup of material that could cause a criticality in the ventilation system (which is an issue in fuel cycle facilities)?]ventilation systems.

5.37.5.35. Redundancy of power to <u>critical_essential</u> parts of the ventilation should be in <u>placeprovided</u>. <u>The Uu</u>se of diesel <u>or /gas</u> generators and <u>an uUninterruptible pPower <u>s</u>Supply (UPS) should be considered.</u>

- 5.38. Appropriate filters should be in place for:
- (e) incoming air,
- (e) outgoing air.

This is largely dependent of the chemical compounds produced and the nuclides used. The filter selection needs to be appropriate for the products being used. Appropriate measures to

Formatted: Default, Justified, Indent: Before: 0 cm, Space Before: 12 pt, After: 6 pt, Outline numbered + Level: 2 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0.95 cm + Tab after: 1.59 cm + Indent at: 0.95 cm, Tab stops: 1 cm, List tab + Not at 1.59 cm Formatted: Default, Line spacing: single, No bullets or

Formatted: Default, Justified, Space Before: 12 pt, After: 6

contain gases which cannot be trapped by filters should be put in place.<u>Ino need to say so</u> much about filters here; there is so much in section 10]-

<u>5.42.5.36.</u> The ducting (piping) for the intake<u>and</u> exhaust air should be constructed of stainless steel<u>or</u> mild steel epoxy lined or galvanized: <u>and should be</u> designed <u>as per in</u> <u>conformityaccordance with</u> industry standards.

5.43.5.37. The supply air to all 'clean rooms' should have terminal HEPA filters, (High Efficiency Particulate Air filters) which should be tested as per-in conformityaccordance with industry standards. The air handling units should have appropriate intake filters and set up to condition the supply air. These air handlers should supply 100% fresh air with no recirculation. The exhaust air should be monitored for radioactive contamination (in the exhaust stack) prior to leaving-discharge from the facility. Further recommendations air emission controls the ventilation system are provided in-(see Section 10).

Site selection [section heading moved down a level, as requested by S. Morita]-

5.44.5.38. During the processes of site selection and site evaluation, particular consideration should be given to potential hazards that cannot be addressed by means of engineering measures, such as hazards relating to flooding and hazards relating to geological phenomena in areas of potential or actual subsidence, uplift, collapse, faulting or, volcanic activity [2931], [I put SSG 35 in here instead of the volcanic hazards guide, as suggested by the Coordination Committee] hurricanes, tornadoes and tsunamis. The hazard analysis should also consider nearby chemical or other industrial installations which that could constitute potential external hazards.

Safety assessment of wWaste management

5.45.5.39. A safety assessment <u>should be conducted</u> of waste management at the <u>radioisotope</u> production facility. <u>The safety assessment</u> should be documented and periodically updated as required. Measures to control the generation of radioactive waste, in terms of type, volume and activity, should be considered put in place throughout the lifetime of a the radioisotope production facility, beginning with the design phasestage, through the selection of materials for the construction of the facility, and by the control of materials and the selection of the processes, equipment and procedures used throughout operation and decommissioning of the facility. <u>The following measures should be put in place-including</u>:

Formatted: Heading 3, Justified, Space After: 6 pt, Line spacing: 1.5 lines

- (i) <u>A handling system for Potentially radioactive</u> liquid waste handling system with liquid wastea decay tank for liquid radioactive waste and chemical waste from quality control (QC) operation activities or target processing (solid targete.g. dissolution of solid targets);
- (ii) <u>Solid wasteA</u> containment and storage room <u>for solid waste</u>;
- (iii) Measures for control of the generation of Ggaseous waste; and-
- (iv) Evaluation of national procedures and availability of a<u>A</u> long_-term storage facility for solid waste (the availability of such a long term storage facility will depend on the national policy and strategy for radioactive waste management [32]). <u>Fis this what you</u> mean by national procedures? also mentioned in para 14.16?]

Safety assessment report

5.46.5.40. The operating organization should demonstrate to the regulatory body how the design of the radioisotope production facility and the related operational operating procedures will contribute to radiation safety during normal operation, to the prevention of accidents, and to the mitigation of the radiological consequences of such-accidents if they were to occur. This information should be provided in the form of a documented safety assessment report describing and evaluating the predicted response of the facility to incidents (including postulated malfunctions or failures of equipment, common cause failures and human errors) and external events of natural origin and human induced origin that could lead to accident conditions. These analyses should include the consideration of combinations of such malfunctions, failures, errors and external events.

5.47.5.41. The results of all the risk assessments referred to in this section should be included in the safety assessment report.

Facility and Equipment Design sSpecification of the facility and equipment

5.48.5.42. An integral part of the safety assessment is the design specification of the facility and the equipment to be utiliszed therein. Each-The design of each radioisotope production facility design-will be unique and dependent onto the purpose of the facility-user requirement specifications[you don't talk about users elsewhere], the proposed site and the local-national regulatory requirements. In addition to the specific design requirements referred to in the previous section on safety assessment, <u>Annex I lists</u> some of the key <u>radiation safety</u> issues which should also to be considered when <u>in</u> setting up a new radioisotope production facility or modifying an existing <u>radioisotope</u> production facility<u>are listed in Annex I of this</u> document.

33

6. RADIATION PROTECTION PROGRAMME

GENERAL

Formatted: Left

6.1. The general objective of a radiation protection programme is to discharge the management's operating organization's [OK?] responsibility for radiation protection and safety through the adoption of management structures, policies, procedures and organizational arrangements that are commensurate with the nature and extent of the radiation risks. The radiation protection programme represents the totality of actions undertaken to achieve the declared aims of the operating organization for radiation protection and safety. [can we delete this? it is a bit waffly, especially I'm not sure what you mean by declared aims]. The radiation protection programme is a key factor in relation to the development and maintenance of the safety culture within an organization [4820], and it should meet the regulatory requirements. The operating organization should strive to keep the magnitude and likelihood of exposures to as low as reasonable achievable. [you've said this before __and anyway it's a requirement] Detailed guidance recommendations on <u>for</u> establishing and maintaining a radiation protection programme that focuses on for the protection of workers is are provided in an IAEA Safety <u>GuideGSG-7 [4820].</u>

6.2. The operating organization should develop, document and implement a radiation protection programme [1820]. This—The radiation protection programme should include information on the radiation protection arrangements, the safety assessment, the measures for implementing the arrangements, and the mechanism for the review and updating of the arrangements.

6.3. Application of the optimization principle should be the principal driving force behind the establishment and implementation of <u>the</u> radiation protection programmes, including in many cases measures to prevent or reduce potential exposures and to mitigate the consequences of accidents if they were to occur. The existence of a radiation protection programme is not sufficient in itself; managers and workers should demonstrate their on-going commitment to the programme and its objectives. Detailed guidance for establishing and maintaining a radiation protection programme that focuses on the protection of workers is provided in an IAEA Safety Guide [18].

6.4. The <u>radiation protection programme</u> should be based on the operating organization's safety assessment, and it should address planned exposure situations as well as reasonably foreseeable <u>radiation</u> accidents.

6.5. The operating organization should-is required to ensure that information on both normal and abnormal operations that are relevant to radiation protection and safety be-is disseminated or made available, as appropriate, to the regulatory body and to manufacturers or suppliers, as specified by the regulatory body [3]. Such information should include maintenance data, descriptions of events, information regarding defects in materials and equipment, weaknesses in operating procedures and, corrective actions, etc. The operating organization should ensure that any new information of this type that is known to manufacturers and suppliers of equipment is obtained from them once it is available. It may be necessary for the operating organization to seek this information from the manufacturer or supplier periodically rather than relying upon them to provide it.

STRUCTURE OF THE RADIATION PROTECTION PROGRAMME

6.6. The guidance on <u>Recommendations on</u> the radiation protection programme is are provided in <u>s</u>-action 3 of <u>GSG-7 Ref. [1820]</u>. The radiation protection programme should include a top level policy document supported by detailed and specific procedures or 'local rules' and a comprehensive system of records (<u>a</u> quality management system).

MANAGEMENT STRUCTURE AND POLICIES

6.7. The radiation protection programme should include a description of the management structure as it relates to radiation-protection and safety. This structure, which may-could be presented in the form of an organizational chart, should show the names of the senior managers responsible for radiation safety and of the various responsible employees (e.g. the radiation protection officerRPO). The chart should clearly show the lines of reporting, from the workers through to the senior managers with overall responsibility. If the operating organization has more than one location of operations, the management structure should clearly specify the responsible persons at each location.

6.8. The radiation protection programme should include a commitment by the management <u>in-to</u> keeping radiation doses as low as reasonably achievable and to fostering a strong safety culture.

Formatted: Left

Assignment of responsibilities for radiation safety

6.9. <u>All_The</u> posts for which responsibilities are allocated should include the senior managers of the operating organization (which has the prime responsibility for safety), the radiation protection officerRPO, the qualified expert/RPA or radiation protection adviser and other workers who have responsibility towards_for_radiation safety, as described in Section <u>42</u>. Personnel <u>must_should [or is this a requirement?]</u> be informed of their responsibility towards_for_radiation safety. Specific responsibilities towards_regarding_certain procedures and records should be allocated to specific workers.

Local rules and supervision

6.10. Local rules that describe the procedures for carrying out radiation work should be developed and written in a language known-that is understood by the people who will follow themthe rules. These local rules should cover all procedures associated with work where there is the potential for radiation exposure, such as routine operations, cell maintenance and transport (see Sections 10 and 11). Greater Eemphasis should be given provided to the development of procedures for target change-outs, maintenance and repairs. Careful consideration should be given to carrying out a pre-survey, and to the development of radiation work permits, which that should include details of required additional surveys, dosimetry, personal protective equipment and maximum occupancy time while working with the targets, based on expected or measured repairs of the operating organization, the radiation protection officer RPO and the worker or group of workers concerneds [correct meaning? one permit per worker?]. The local rules are an important tool in the restriction of radiation doses. They should include sufficient information and guidance to allow workers to carry out their duties safely and in compliance with regulatory requirements.

6.11. Management should ensure that all relevant persons have read and understood the local rules. A copy of the local rules should be provided to all workers and other relevant persons, and additional copies should be available displayed in the work area. In smaller organizations with a limited amount of work, it may be appropriate to have one set of local rules covering all procedures. Management should ensure that all relevant persons have read and understood the local rules.

6.12. In larger organizations, it might be appropriate to have several sets of site specific local rules, depending upon the nature, <u>likelihood and</u> magnitude and likelihood of exposures. A <u>fFacility specific procedure-local rules</u> should also be established. <u>Fis the meaning of this</u> sentence clear or could it be deleted? what is the intended difference between site specific and <u>facility specific?</u> Workers should be informed <u>on-about all</u> such procedures.

6.13. Visitors should be provided with radiation safety information. Accal-rules_that is tailored to the purpose of their visit. If visitors are to be escorted at all times, a short briefing on arrival may be sufficient.

6.14. Itinerant workers should be made aware <u>of</u> and trained in relevant sections of the local rules. Detailed <u>guidance-recommendations form</u> itinerant workers <u>is-are</u> provided in <u>GSG-7</u> the <u>sSafety gGuide Ref. [1820]</u>.

6.15. The operating organization should appoint at <u>[already talked about the appointment of at</u> <u>least one employee in para 4.15]</u> least one employee as a radiation protection officer <u>RPO</u> to <u>should</u> oversee the day to day implementation of the radiation protection programme and to carry out duties as required by the programme. Details of the duties of the <u>radiation protection</u> <u>officer RPO</u> are <u>given-provided</u> in Section 4.

6.16. The Opperating organizations should is required to ensure that female employees workers who are fiable to enter controlled or supervised areas are provided with information regarding the risks to an embryo or foetus from exposure to radiation and the importance for a female worker of notifying their her employer as soon as soon as soon as possible if she suspects that she is pregnantey is suspected. Following declaration After a worker has notified her employer of her pregnancy, the employer is required to adapt the working conditions to ensure that the embryo or fetus is afforded the same broad level of protection as is required for members of the publicrestricted radiation doses will apply. Considerations on relating to potential internal contamination should be given for breast feeding female workers if they are working with unsealed radioactive materials (see also sSection 6 of GSG-7 Ref. [1820]).

Designation of controlled areas or supervised areas

6.17. <u>Paragraphs 3.88 to 3.91 of GSR Part 3 [3] establish requirements on controlled areas</u> and supervised areas. The radiation protection programme should describe how controlled areas⁷ and supervised areas⁸ are to be designated <u>for-at_the radioisotope_isotope_production</u> facility. Controlled areas should be <u>established with the goal of used to</u> restricting exposures of workers in <u>radioisotope_isotope</u> production facilities. The designation of <u>such-controlled</u> areas <u>and supervised areas</u> should be based on the safety assessment.

6.18. Normally the area at the side of the cells where transfer containers are coupled should be designated as a controlled area. The front of the cell should be designated <u>as</u> a supervised area because there is a lower probability of contamination and radiation. The internal compartment of all hot cells should be designated as controlled areas.

6.19. The active maintenance area at the side of the cells where transfer containers are coupled should be designated as a controlled area because of the higher probability of contamination and radiation in that area.

6.20. The area where the products are received into the hot cell and dispensed normally have has a higher probability for contamination and radiation and should therefore be designated as a controlled area.

6.21. Normally in -the accelerator room there should be lowthe probability of contamination and radiation will be low,-[not actually a should statement, I think]; however, considering the risks associated with the failure of a target, the accelerator room -can-should [?] be operated designated as a controlled area.

Periodic reviews and audits of the performance of the radiation protection programme

6.22. As an integral part of the operating organization's management system, the radiation protection programme and its implementation should be assessed on a regular basis. This periodic review should <u>be carried out to</u> identify problems to be addressed and any modifications that could improve the effectiveness of the radiation protection programme.

⁷ A controlled area is a defined area in which specific protection measures and safety provisions are or could be required for: <u>(a)</u> controlling <u>normal</u> exposures or preventing the spread of contamination <u>during in</u> normal working conditions; and <u>(b)</u> preventing or limiting the extent of potential exposures <u>[3]</u>.

⁸ A supervised area is a defined area not designated a controlled area but for which occupational exposure conditions are kept under review, even though no specific protective measures or safety provisions are normally needed [3].

of the persons who will conduct them, their frequency of audits, the expectations of the audit team, and the procedures for reporting of results and their follow-up.

Quality assurance Management system and process improvement

6.24. Radioisotope production work and its associated activities should be carried out in accordance with the established management system. This management system should be designed to ensure that all equipment and safety systems are regularly checked and tested, and that any faults or deficiencies are <u>promptly</u> brought to the attention of the management and <u>quickly are promptly</u> remedied.

6.25. The mManagement should also ensure that the correct operational operating procedures are being followed, and that the quality assurance programmemanagement system specifies the relevant checks and audits to be made and the records to be kept. The relevant regulatory requirements should be taken into account and reflected in the content and details of the quality assurance programmemanagement system.

6.26. The management system should include a mechanism for the collection and feedback of lessons learned [not yet learned] from day to day operations, emergencies and incidents (including those reported both within the organization and in external reports by other organizations), and how these lessons can be used to enhance safety.

HEALTH SURVEILLANCE PROGRAMME

6.27. The radiation protection programme should include details of a programme for periodic health surveillance of radionuclide radioisotope production personnel and other employees workers as appropriate. The objective of a health surveillance programme is This should include a requirement to assess the initial and continuing fitness of workers for their intended tasks. A qualified expert/RPA or radiation protection adviser and/or an appropriately qualified medical doctor should be consulted in the drawing upregarding the establishment of the programme for health surveillance, and it which should be consistent with regulatory requirements.

RADIATION SAFETY COMMITTEE

6.28. A radiation safety committee should be established for the purpose of regularly reviewing the performance of the radiation protection programme. <u>As regardsFor radioisotope</u>

production sitesfacilities located within In-a hospital, the radiation safety committee for the hospital-may be dedicated to radiation safety or it may have in addition other (conventional) safety related responsibilities, while it should also look at the radiological safety aspects of the cyclotron/linear accelerator. In the case where the hospital doesn't have a radiation safety committee such a committee should be established. This committee may be dedicated to radiation safety or it may have other (conventional) safety related responsibilities. The radiation safety committee should include the senior manager(s) responsible for radiation safety, the radiation protection officerRPO(s), qualified experts/RPA or radiation protection advisers and representatives of the workforce. The responsibilities of the radiation safety committee should include, but not be limited to:

- (a) <u>Conducting Rregular reviews of all aspects of the radiation protection programme;</u>
- (b) <u>Conducting Rr</u>eviews of occupational radiation doses and any accident reports prepared by the radiation protection officer<u>RPO</u>;
- (c) Making recommendations for improvements in the radiation protection programme;
- (d) Provision of guidance and direction on the performance of the <u>radiation protection</u> officer's <u>RPO's-</u>duties;
- (e) Preparation and dissemination of regular reports to all staff about relevant radiation safety issues;
- (f) Reviews of the emergency preparedness and response plan for the facility.

7. TRAINING AND EDUCATION QUALIFICATION [AS IN DS419?]

GENERAL

7.1. Persons performing work in controlled areas within The operating organization of the an radioisotope_isotope_production facility are is_responsible for ensuring that their work is carried out safely and in compliance with all relevant regulations and safety standards [3]. The Ooperating organizations should, therefore, ensure that radiation work in the facility is carried out only by workers who are trained <u>fqualified?</u>, and who are competent and trained in radiation protection and safety. Apprentices and trainees should work under direct supervision of a suitably trained person.

7.2. The workers in <u>a radioisotope isotope</u> production facilit<u>yies</u> should have <u>undergone</u> training and <u>received</u> qualifications that are specifically related to their area of responsibility. Some of this training <u>may-might have</u> include<u>d</u> only a limited amount of training in radiation protection and safety. In <u>this-such_cases</u>, <u>they_this training_should</u> be supplemented with additional training specifically in radiation protection and safety. Such additional training may be provided by specialized training organizations rather than by the operating organization.

7.3. Designated emergency workers <u>are required to be should [maybe a requirement? see</u> <u>GSR part 7, Req 25] be qualified [qualified in what?] and trained in arrangements for</u> preparedness <u>for and response for to an emergency that can arise in the course of the</u> production, use or transfer of radionuclides (see Section 16).

TRAINING PROGRAMME

7.4. The radiation protection programme should describe the full scope of the training programme in radiation protection and safety for all <u>employees_workers_directly</u> involved in routine <u>radio</u>isotope production activities and emergency response. It should include <u>basice</u> radiation <u>sawareness</u> programmetraining in radiation protection <u>[this is what it's called in</u> <u>GSG-7]</u>, where appropriate, for other <u>staffpersonnel</u>, including managers, research scientists, laboratory technicians, trainees, workers such as cleaners and maintenance <u>staff_personnel</u> who <u>may_might_be</u> inadvertently exposed, and contractors. The radiation protection programme should also specify the minimum educational and professional qualifications for all relevant staff including those involved in an emergency response, especially the <u>radiation</u> protection <u>officerRPO</u>, hot cell or cyclotron <u>or</u>_flinear accelerator operators, and pharmacists, in accordance with regulatory requirements.

Formatted: Left

7.5. The requirements for keeping t<u>T</u>raining records keeping should be consistent with regulatory requirements [3] and recommendations[is 'regulatory recommendations' elear?], and they should be specified in the radiation protection programme.

7.6. The training programme should be reviewed periodically or when there are significant changes in design of the facility or processes.

Design of a training programme

7.7. The operating organization should define necessary competences and knowledge for operating the facility and accelerator. This training programme in radiation protection and safety may be provided by the operating organization or by a specialized training organization. The operating organization should take into consideration the levels of competence based on the workers' training and experience. In the case where <u>an-the</u> operating organization does not have the capability or resources to establish a training programme, the workers should attend a training programme on radiation protection and safety provided by competent training providers, including post-secondary education institutions, radiation protection institutions and training consultants.

7.8. Programmes should be established for the different levels of training corresponding to the responsibilities of the worker. The workers could be divided into the following groups:

- -Hot cell and cyclotron or Alinear accelerator operators;
- -Pharmacists:
- -Radiation protection officers:
- -Laboratory technicians;
- -Research scientists;
- -Maintenance personnel, packaging personnel and decontamination workers;
- -Operators handling radioactive waste.

7.9. The training programme should establish the criteria for passing theoretical and practical examinations, as well as the procedures to be followed if an applicant fails an examination. The details of the training programme should be incorporated into the radiation protection programme.

STRUCTURE AND CONTENT OF THE TRAINING COURSES

Formatted: Font: (Default) Times New Roman, Complex Script Font: Times New Roman

42

7.10. Each training course should be structured around specific aims and objectives and should be customized to the needs of the target audience. The training may include the following topics: [pls review all lists of bullets in paras 7.10 to 7.17 for consistency and accuracy; some are hugely detailed, while some seem rather vague]

- Basic <u>concepts of</u> ionizing radiation-concepts;
- Ionizing <u>R</u>radiation quantities and units;
- <u>Instruments for detection of Hionizing radiation-detecting instruments;</u>
- Biological effects of radiation;
- <u>The Ssystem</u> of radiation protection (<u>the</u> radiation protection principles of justification, optimization and dose limitation);
- Regulatory requirements;
- <u>The Dd</u>esignation of controlled areas and <u>of</u>-supervised areas; <u>local rules and</u> <u>procedures;</u>
- Dose limits, dose constraints and investigation levels;
- <u>The Ee</u>ffects of time, distance and shielding;

Individual monitoring, (external and internal monitoring) and how to interpret their doses measurements;

- Working practices to limit doses and maintain them as low as reasonably achievable;

- <u>The Rradiation protection programme;</u>
- Emergency preparedness and response.

7.11. Topics in the area of Ppractical radiation protection should include:

- Handling of radioactive materials, including those-radioactive material in unsealed forms;
- Implementation of emergency arrangements;
- Specific task related issues.
- 7.12. For Hhot cell operators, the training should additionally cover:
 - Operation of hot cells (e.g. opening hot_cells for operation or maintenance-etc.);
 - <u>Handling of Mm</u>anipulators handling (e.g. tongs).

Formatted: Indent: Before: 0.63 cm, Hanging: 0.63 cm

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

- 7.13. For Rresearch scientists, the training should additionally cover:
 - Specific training on radiation protection and working procedures tailored to their nature of <u>their</u> work.
- 7.14. For Mmaintenance services workers, the training should additionally cover:
 - Maintenance on of the target transfer [?] system, radio isotope transfer system, hot cells and manipulators and operations significant to radiation safety.

<u>7.15. For individuals carrying out D</u>decontamination services, the training should additionally cover:

- Decontamination after incidents involving radioactive contamination incidents.

7.16. For <u>Waste</u> operators of waste management facilities, the training should additionally cover:

- Handling instructions for radioactive waste;
- Waste management procedures;
- Task related practical information;
- Storage and shipment of radioactive material;
- Local rules and procedures. [surely this bullet would apply for everyone?]-
- 7.17. For Sshipping clerks, the training should additionally cover:
 - <u>International and national requirements on transport of radioactive material</u> training on shipment of radioactive material;<u>[we don't usually promote training from</u> <u>specific organizations</u> and IATA mostly trains pilots and airline workers, right?]
 - Storage of radioactive materials;
 - Access control procedures;
 - Security procedures;
 - Local rules; <u>[surely this bullet would apply for everyone?]</u>
 - Management of Practical radiation protection including handling and transport of radioisotopes; [??]
 - Transport of radioactive materials;
 - Measurement of radiation fields and the units of measurement;

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

Formatted: Body Text, Indent: Before: 0 cm, First line: 0 cm, Space Before: 6 pt, After: 6 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0.63 cm, Tab stops: Not at 0.63 cm

Formatted: Indent: Before: 1.14 cm, No bullets or numbering

 Accidents and other incidents involving the production, use and transport of radioisotopes, their consequences and lessons learned.

7.11.7.18. The training should provide-include practical exercises, including the rehearsal ofdrills involving dealing with abnormal events (e.g. a broken-vial with containing a medical isotope that breaks during dispensing). However, actual radioactive sources, unless they are exempt, should never be used in such rehearsalstraining. Not in use Ceells that are not in use can also be used for training in the use of manipulators and coupling and uncoupling of transfer containers.

7.12.7.19. <u>A-The radiation protection officer RPO</u> and a qualified expert/RPA or radiation protection adviser should provide advice on staff training needs and on how those needs may <u>can</u> best be satisfied. In many cases, a the radiation protection officer RPO should will [not really a should statement] be able to provide much of the necessary training.

7.13.7.20. Where appropriate, workers should receive adequate training and refresher training in the proper use of personal protective equipment.

REFRESHER TRAINING

7.14.7.21. Management should ensure that their workers' knowledge and skills are kept up to date through a programme of refresher training. Such training should include a review of the fundamentals of protection and safety, and information on changes to equipment, policies and procedures, and possible any changes in regulatory requirements.

7.15.7.22. The frequency of refresher training should be consistent with regulatory requirements. Refresher training is typically given at intervals of less than two years but not exceeding five years. However, changes in regulations or notifications occurrences [?] of safety issues should be disseminated as written instructions as soon as practicable, and then followed up by inclusion in the next scheduled refresher training.

8. INDIVIDUAL MONITORING OF WORKERS

INDIVIDUAL DOSE ASSESSMENT AND RECORD KEEPING

Formatted: Left

8.1. <u>The Pp</u>roduction of radioisotopes increases the potential for exposure to ionizing radiation, radioactive substances and aerosols by workers. External ionizing radiation fields are created during the process of target irradiation.

8.2. For radiation safety and regulatory compliance, a<u>A</u>ll workers who usually work in a controlled area at a radioisotope production facility, or who occasionally work in a controlled area and may receive a significant dose from occupational exposure, with potential for radiation exposure in controlled areas should are required to be monitored, where appropriate, to assess their individual dose due to external and internal radiation dose exposureas appropriate [3].[seems like GSR Part 3 para 3.100 so I've reworded it as such]

8.3. Target assemblies are encapsulated to limit the release of radioactive material or aerosols to the work environment. However, work activities during radioisotope production, target processing, radiochemical separation and purification activities, and radioisotope handling and packaging activities increase the potential for release and inadvertent intakes of radionuclides by workers. For work activities having increased potential for internal exposure, workers should be monitored by direct measurements and indirect bioassay to assess internal intake of radioisotopes [4820].

8.4. The designation of controlled <u>areas</u> and supervised areas should be reviewed regularly, and may be changed or extended during initial installation, maintenance, and in order to meet the operational requirements of the facility.

8.5. All visitors <u>in the controlled areas</u> should be supplied with individual dosimeters <u>depending up on the radiation levels in the areas to be visited.</u>[really all visitors?] The isotope production facility should record the <u>A record of the</u> dose received by the <u>each such</u> visitors <u>should be retained</u>.

8.6. <u>Records of Dd</u>osimetry records <u>[or 'records of occupational exposure', as in the BSS?]</u> provide the means for tracking individual <u>occupational exposure radiation (external and internal exposure)</u> <u>s [?] and internal dose</u> from sources of ionizing radiation for both routine work and inadvertent or accidental exposures.<u>-Radiation dose R</u>records <u>of doses</u> should be used to demonstrate regulatory compliance and support radiation safety planning <u>of activities</u>

[what is radiation safety planning?]. These records should include the results of individual worker-individual monitoring of workers for both external radiation-exposure and intakes of radioactive material. Records should include all applicable measurement data, measurement dates and times, names of personnel monitored individually, and methods used to measure external dose or calculate internal dose. <u>Records of Personal-occupational</u> exposure and dosimetry records <u>fis there an intended difference?</u> should be maintained in retrievable forms, as specified in <u>paragraph-para.</u> 3.104 of the GSR Part 3[3].

8.7. <u>The States should establish a national dose register registry for workers in order to accumulate collect and maintain records of all doses workers received by workers at different facilities. Detailed guidance on dose record keeping records of occupational exposure is provided in <u>GSG-7 the sSafety gGuide Ref. [1820]</u>.</u>

EXTERNAL DOSIMETRY EXPOSURE

8.8. Individual monitoring tracks individual cumulative exposure, <u>gives_provides_input in</u>to <u>the</u> optimizsation process and the assessment of exposures in a radioisotope production facility and provides essential information for record keeping. <u>Guidance-Recommendations</u> <u>onfor</u> establishing external radiation monitoring for individual workers <u>is given-are provided</u> in <u>GSG-7 [1820]</u>.

8.9. Workers who enter controlled areas in <u>the radioisotope production facilities facility</u> should be monitored continuously for exposure to ionizing radiation using appropriate methods and technology.

8.10. A programme for individual monitoring of external radiation exposure is intendedshould be established to demonstrate that workers' exposures are being monitored, to provide information for the optimization of protection and safety and to verify the adequacy of work procedures. Guidance-Recommendations on determining the type of radiation field (e.g. photon, beta, neutron or other high energy particles) present in the working environsareas, on establishing monitoring programmes for external exposure, on selection of appropriate dosimeters, on interpretation of resultsmeasurements, on record keeping and on quality management is given are provided in GSG-7 [1819].

Types of external-monitoring for external exposure

Formatted: Left

Formatted: Tab stops: 1 cm, List tab + Not at 0.63 cm

8.11. Each worker should wear an above-the-waist, whole_-body dosimeter (e.g. a film_badge, thermoluminescent chipdosimeter, or optically stimulated luminescentce-crystal_dosimeter) capable of accurately recording and integrating cumulative exposure to gamma radiation.

8.12. Hot cell operators, <u>radiation protection officersRPOs</u>, pharmacists, decontamination workers, laboratory technicians, researchers and maintenance staff who routinely enter controlled areas should be subject to individual <u>dose</u> monitoring. <u>These individuals should</u> <u>wearIn addition to</u> whole body <u>monitors dosimeters (e.g. a film badge, thermoluminescent dosimeter or optically stimulated luminescent dosimetersee para. 8.11), these individuals <u>should wear-and</u> an electronic personal dosimeter to ensure effective dose management. [pls <u>check and compare paras 8.11 and 8.12]</u></u>

8.13. Workers who handle or process beta-emitters in close proximity to the eyes and skin surfaces should wear multi-purpose (gamma, beta) dosimeters with capability for thinwindow beta-ray detection.

8.14. Appropriate extremity personal dosimeters -should be worn for situations requiring the monitoring of exposure to of the hands.

8.15. Appropriate eye dosimeters should be worn for situations requiring the monitoring of doses to the lens of the eye-doses. [3033].

8.16. <u>The wW</u>orker<u>s</u> should position dosimeters under any protective clothing worn (-under the lab coat, apron or overalls) in order to reflect the dose to the body. <u>It-This</u> will also prevent the <u>radioactive</u>-contamination of the dosimeter. However, in the case of <u>exposures</u> to beta <u>radiationexposures</u>, dosimeters should be positioned appropriately to avoid shielding by protective clothing.

8.17. The dDosimeters should be read at least <u>quarterly every three months</u> or more frequently depending on the nature of <u>the</u> work and <u>the</u> technical specifications of the dosimeter.

8.18. The eElectronic dosimeters should be used in an <u>radio</u> isotope production <u>environment</u> <u>facility</u> whenever multiple or variable work activities are performed, such as equipment maintenance or hot cell modifications, involving potentially hazardous radiation levels.

8.19. The tools and procedures for individual monitoring for exposure of workers, including the type of dosimeter <u>required_necessary</u> and the necessary frequency of replacement, should be chosen in consultation with <u>a_the radiation protection officer RPO</u> or <u>with a</u> qualified expert or <u>radiation protection adviserRPA</u>, in accordance with <u>the regulatory</u> requirements of the regulatory body. The dDosimeters should be provided to and processed by a laboratory or company that has been authorized by the regulatory body and is traceable to a standards dosimetry laboratory approved by the regulatory body.

8.20. The operating organization should make arrangements to ensure that dose records are maintained for each worker in the manner specified inaccordance with regulatory requirements (see GSR Part 3_[3], para 3.104). The Operating organizations should ensure that personal dose records of individual dose [OK? 'personal dose' tends to be used only in certain quantities, e.g. personal dose equivalent] are provided to workers upon termination of their employment and are available to the individual workers at other times.

8.21. <u>The Oo</u>perating organizations should prepare procedures describing the way in which individual dosimeters are to be administered, and; these procedures should <u>include address</u> the following:

- (i) Ordering and receiving dosimeters from the dosimetry laboratory;
- (ii) Distribution of dosimeters to monitored workers;
- (iii) Collection and dispatch of dosimeters to the dosimetry laboratory for processing;
- (iv) Review and maintenance of dose records.

8.22. <u>The Oo</u>perating organizations should provide suitable storage facilities for personal dosimeters not in use that protect the dosimeters from inadvertent exposure to radiation and from adverse environmental conditions such as extremes of heat or cold and/or humidity. Personal dosimeters should not be stored close to any area where dose rates are above normal background levels <u>of radiation</u>. Normally dosimeters should not be put through scanners -that utilize X rays (e.g. <u>Mm</u>ail inspection systems <u>and</u>, airport security scanners <u>-tec</u>). In exceptional circumstances, adequate control <u>or background reference dosimeters</u> [what is this?] may be used to evaluate the actual exposure of the dosimeters.

8.23. <u>In accordance with para. 3.83(b) of GSR Part 3 [3], Mm</u>onitored workers should be required to take good care of their dosimeters, and to take precautions to protect them from loss, theft, tampering or damage and from inadvertent exposure to radiation. Workers should

return dosimeters promptly at the end of the specified period of wearing. Workers should inform a <u>radiation protection officer RPO</u>-without delay if a dosimeter is missing or damaged or if it has been exposed to radiation when they were not wearing it.

8.24. If a dosimeter is lost, all reasonable steps should be taken to recover it. If the dosimeter cannot be located, <u>the</u> operating organizations should carry out an investigation and should prepare a report that includes an estimate of the dose received by the worker for the relevant period of time. In some States, the approval of <u>the</u> regulatory bod<u>vies</u> may be required prior to the entry of such estimates into a person's dose record.

INTERNAL DOSIMETRY EXPOSURE

8.25. The probability forlikelihood [probability implies some kind of a number; do you mean that?] of internal intakes of radionuclidesactive substances by ingestion or inhalation should be established during in the safety assessment of for the radioisotope isotope production facility. A monitoring programme should be established in cases where there is a probability likelihood of such intakes. The frequency of the monitoring and the type of monitoring should be determined from the level of probability for theore the basis of the likelihood of such intakes. Guidance on internal dosimetry is established in GSG-7 Ref. [1820].

Types of assessment of internal dosimetry exposure

8.26. Methods for <u>the</u> assessment of radioisotope intakes include direct in vivo counting, bioassay measurements of urine, faeces, sputum, nasal swipes, or blood, and biokinetic modelling using measurement data and information <u>on-about</u> the chemical and physical characteristics of the material to which workers <u>may-might</u> be exposed.

8.27. Methods used to assess radioactivity intakes and uptakes should be appropriate for the radioisotopes under consideration <u>is e.g.for example</u>, for beta emitters a 24-hour urine sample should be taken and sent for analysis for the isotope in the urine. From the The results, of such measurements should then be used to calculate the internal doses should be calculated for intakes of radioactive materials by workers at isotope production and processing facilities.

8.28. Biokinetic models have been developed for a broad array of <u>forms of radioactive</u> material-forms, modes of intake, and metabolic pathways to facilitate calculation of internal dose to the whole body, critical organs, and tissues [$\frac{1820}{1.000}$]. <u>Calculations of H</u>internal dose

calculations are <u>typically</u> facilitated using computer software or dose_-conversion factors per unit intake.

Criteria for internal monitoring

8.29. Under normal conditions the contamination level in the air, in general_a should not exceed_1/10 of DAC (the derived air concentrations) of the isotope ¹³¹I. Guidance on <u>derived</u> air concentration DAC values and criteria for internal monitoring are-is available-provided in the IAEA Safety Guide on occupational exposureGSG-7 [1820].

8.30. In cases where there is a <u>probability_likelihood</u> that contamination in the air could exceed 1/10 of <u>the derived air concentration</u> DAC of the applicable isotope, a routine internal monitoring programme <u>appropriate for this isotope</u> should be established for the workers that would be appropriate for this isotope.

INVESTIGATION OF <u>OVEREXPOSURES</u> DOSES <u>EXCEEDING DOSE LIMITS [OR</u> INVESTIGATION OF OVEREXPOSURES?]

8.31. The operating organization should instruct workers to notify the <u>radiation protection</u> <u>officer RPO</u>-immediately if they know or suspect that they have been exposed to high levels <u>of</u> radiation <u>fields (above the dose constraints ore.g. if the radiation field experienced by the</u> <u>worker increases unexpectedly-abnormal)[OK?]</u> or <u>to</u> elevated airborne contamination. If the individual(s) concerned was wearing a personal dosimeter, it should be sent immediately to the <u>a</u> dosimetry laboratory and the laboratory should be informed of the urgency of the case. In the case of exposure to airborne contamination, the <u>person-individual</u> should be monitored for the appropriate isotope for estimating internal doses.

8.32. The operating organization should_is required to conduct a formal investigation, as required_specified_by the regulatory body, whenever_if_the recorded dose exceeds the investigation level. The investigation should_is required to be initiated as soon as possible following-after the event, and a written report should-is required to be prepared concerning its the cause of the event. This report should-is required to include a determination or verification of any doses received, details of corrective or mitigating actions_carried_out, and instructions or recommendations on how to avoid a recurrence of the event [3].

8.33. The report <u>is required to should</u> be provided to all concerned parties within the appropriate time frame, as required-prescribed by the regulatory body [3].

Formatted: Left

Formatted: Justified, Tab stops: Not at 0.63 cm

9. WORKPLACE MONITORING

9.1. Paragraph 3.96 of GSR Part 3 [3] states:

<u>that</u><u>"</u><u>r</u><u>R</u>egistrants and licensees, in cooperation with employers where appropriate, shall establish, maintain and keep under review a programme for workplace monitoring under the supervision of a <u>radiation protection officer RPO</u>-or qualified expert/<u>RPA</u>."-

9.2. Paragraph 3.97 of GSR Part 3 [3] states:

"The type and frequency of workplace monitoring-shall:

(a) <u>Shall Bb</u>e sufficient to enable:

- (i) Evaluation of the radiological conditions in all workplaces;
- (ii) Assessment of exposures in controlled areas and supervised areas;
- (iii) Review of the classification of controlled areas and supervised areas;
- (b) <u>Shall Bb</u>e based on dose rate, activity concentration in air and surface contamination, and their expected fluctuations, and on the likelihood and magnitude of exposures in anticipated operational occurrences and accident conditions."

9.3. Detailed <u>guidance-recommendations</u> regarding workplace monitoring, including the use of <u>fixed-installed [I prefer installed because otherwise it can look like 'fixed dose rate'; but</u> <u>let's discuss if necessary (compare with GSG 7)]</u> and portable radiation dose rate meters, contamination control and air sampling are provided in <u>GSG-7 Ref. [1820]</u>.

9.4. Dosimetry should be performed by calibrated and suitable instrumentation. Detail<u>eds of</u> the guidance-recommendations on the selection of the proper radiation survey instrument for a given application are provided in <u>Refs [17, 18]GSG-7 [20].[I don't think that GSG 13</u> contains relevant recommendations (though its predecessor GS G-1.5 probably did)]. The following subsection summarizes information <u>in-with</u> regard to the radiation meters and monitors that are normally employed in <u>the</u>-radioisotope production facilities.

RADIATION MONITORS

Fixed-Installed and Pportable Rradiation Ddose Rrate Mmeters

Formatted: Tab stops: Not at 0.63 cm

Formatted: Heading 2

9.5. For both <u>fixed_installed_and</u> portable dose rate monitors, the detector probes and detector windows should be carefully selected to suit the type of radiation being emitted (e.g. photon, beta or neutron). Under production conditions in the hot cell it is possible to measure beta emitting products <u>for to measure beta radiation?</u>] at the outlet of the hot cell after the end of the technology process. It is not often practicable to measure beta radiation inside the hot cell because of the presence of mixed gamma and beta radiation. Depending on the activities in the <u>radioisotope</u> production facility, a range of radiation detectors may be requirednecessary.

9.6. Fixed<u>or installed</u> radiation-dose rate meters are normally referred to as area monitors. Area monitors serve as an important safety feature to ensure the safety of workers in the workplace. Alarms <u>levels are should be set-used</u> to alert the workers <u>to of</u> an elevated radiation dose rate. Both audible and visual alarm signals should be <u>available-provided</u> to warn personnel on the<u>of an</u> abnormal situation in the monitored area. The requirement for the number and location of fixed radiation dose rate metersarea monitors should be <u>determined</u> based upon the safety assessment. Locations for fixed dose rate area monitors can include:

- (a) <u>D</u>door openings from hot cells, cyclotron or Alinear accelerator bunkers and caves, with a probe inside the enclosure interlocked to the door control;
- (b) Locations where maintenance activities may inadvertently cause elevated dose rates, for example at the front of hot cells, shielding covering filtration, <u>the</u> ventilation systems room and, the waste room, etc.

<u>9.7. An important final</u>-consideration in determining the location and alarm presetspre-setsof-for area monitors is the avoidance of nuisance alarms. In a <u>radioisotope</u> production facility, loaded-packages and raw materials are in movement throughout the site, so it is important to have area monitors set not to alarm due to such routine processes. Routine operational verifications should be preceded by a verbal alert that testing is happening.

9.7. If these steps are not followed, workers may not be alerted to an irregular condition.[this doesn't add much concrete info]

Considerations for Portable Dose Rate Meters[vou don't need this heading the previous heading covers both fixed and portable]

9.9.9.8. <u>Trained pPersons carrying out work in radioisotope production facilities should be</u> equipped with adequate radiation detection equipment are necessary to carry out work in Formatted: Body Text, Tab stops: Not at 0.63 cm

Formatted: Body Text, None, Space Before: 0 pt, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0 cm, Don't keep with next, Don't keep lines together, Tab stops: 1 cm, List tab + Not at 0.63 cm Formatted: Body Text, Tab stops: Not at 0.63 cm radioisotope production facilities. The production facilityoperating organization should ensure the availability of the required number of portable detectors in good condition<u>and–Such</u> portable detectors mightmay include different dose rate meters, for example:

- Large volume, thin end window open air ionization (ion) chambers with thin end windows for evaluation of beta, and low energy gamma (<~50 keV) dose rates evaluation; These ion chambers may have desiccants inside, which is an-and are important considerations as humidity fluctuations may-might render the chamber inoperable. These detectors are useful for obtaining a reliable dose rate at 1 meter metre for transport measurements; however, because of their size, they are difficult to use to evaluate contact readings or small diameter beams. High dose rate (smaller volume) open air ion chambers with thick side walls are useful at for localizing high energy beta activity or /contamination in production hot cells.</p>
- Large volume pressurized ion chambers: tAlthough thesey are not capable of detecting beta or low energy gamma detectionradiation, they are useful for providing stable dose rate measurements and do not suffer from humidity fluctuations as they must beare sealed in order to maintain their pressurized gas. These detectors are useful for obtaining a reliable dose rate at relatively close-larger [2] at distances to the source.
- Proportional detectors<u>counters</u> <u>[2]</u>: <u>These</u> may be used as dose rate meters, though they are more commonly designed for use as contamination meters. When used as dose rate probes, proportional <u>detectors counters</u> <u>will-are</u> normally <u>be</u> sealed and <u>therefore do</u> not suffer the effects of humidity.

Geiger-M<u>ü</u>ueller (GM)-type detectors<u>: These</u> are available in a variety of sizes and configurations. Larger probes have increased dead times and are not suitable for high dose rate measurements, whereas smaller volume probes -can be used in evaluating dose rates produced by small diameter beams. <u>Geiger-Müller_GM</u>-probes smaller than an ion chamber provide better evaluation for the for dose rates near contact on surfaces. Thin end window <u>Geiger-Müller_GM</u>-probes may be suit<u>ableed</u> for beta detection, though they typically over respond to low energy gamma rays via the thin window. Thin end window <u>Geiger-Müller_GM</u>-probes often have greater directional dependence than other detectors, which is an important consideration in training <u>of</u>-staff in their use. <u>Geiger-Müller_GM</u>-probes are sealed and so do not suffer from humidity fluctuations. They are the most commonly used detector type because of their cost, ruggedness and ease of use_— but they are not best suited to all types of radiation.

Formatted: Highlight

- A useful type of pPortable dose rate meters in a production facility is one-that haves an extending pole:- These are useful in radioisotope production facilities as Ddistance can be maximized using an extender type detector to protect the employeeworkers when encountering high or unknown dose rates are suspected. Extending detectors are essential tools at many radioisotope production facilities and are used to assess cyclotron and target interventions, dose rates around duct work and hot cells, and for routine surveys. The information gathered by an extendinged detector will inform radiation safety staffworkers of whether it is safe to proceed with work at a closer distance and will be able toenable estimation of e-the length of time permissible to perform the planned work.
- Moderator based survey instruments: <u>These</u> are <u>the a</u> common types of equipment used in the case offor neutron surveys.⁵ <u>Examples includesuch as</u> portable proportional counters filled with BF₃ or ³He gases.

Detection of Ssurface cContamination Detection in the production premises

9.10.9.9. Contamination surveys <u>can_are_sometimes be_performed using direct</u> measurement, but when there are varying or elevated <u>radiation</u> backgrounds<u>radiation levels</u> in the <u>radioisotope</u> production facility, <u>such surveys</u> they are more frequently performed by <u>taking_swipeing_samples</u>. Routine surveys include checks of equipment and personnel at <u>barrier doors</u>, and routine floor and surface checks. Minimal frequencies for routine floor and surface checks should be defined by the operating organization, but the practice should be commensurate with the risks at the production facility and may vary from weekly at a small facility, to daily or multiple times a day at large production facilities. [this is all below in para 9.13]

9.11.9.10. Contamination monitoring should be performed when utilizing glove-boxes and fume hoods or when non-routine work is being carried out. Depending up on the potential for personal contamination of individuals, appropriate hand and foot monitors may should [?] may be installed at the exits of the controlled areas.

9.12.9.11. Surface contamination surveys fall into two categories at a production facility: routine <u>surveys</u> and <u>surveys</u> conducted as and when <u>needednecessary</u>. When background radiation levels are varying or elevated, cContamination surveys are often performed by taking swipeing samples or other indirect means[is this sentence still correct when reordered?] when the background radiation levels are varying or elevated. Routine contamination survey

frequencies [frequencies are mentioned in para 9.13] and eCriteria for acceptable surface activity levels (in terms of activity per /unit area, Bq/cm²) should be defined in the radiation protection programme. If necessary these values can be conservatively converted to the units in which of the detector reports (cps or cpm) for ease of use by the operator. Factors to that should be considered during such instances in conducting surface contamination surveys -are swipe efficiency, detection efficiency of the contamination meter for the radioisotope concerned, -geometry of the detector surface to swipe area detector surface/swipe area of the detector [OK?], and counting time.

9.14.9.13. Routine contamination surveys are an essential part of application of the conceptof the defence in depth-concept. Routine surveys include checks of equipment and personnel at barrier doors, and routine floor and surface checks. Minimumal frequencies for routine floor and surface checks may should [?] be determined specified in the radiation protection programme and may can vary from weekly at a small facility, to daily or multiple times a day at a large radioisotope production facilities facility. Routine floor surveys in general areas and hallways provide an indication if of whether contamination is being tracked from processing areas. Indirect floor surveys can be performed by taking swipeing samples with a dry mop with a replaceable cloth and directly checking the mop for contamination.

9.15.9.14. <u>As needed, eIn addition to such routine surveys, c</u>ontamination surveys should <u>also</u> be performed when:

- a) Litems enter or exit, cells, glove-boxes and fume hoods;
- b) <u>T</u>the potential to perform intervention work is evaluated in areas <u>which that may might</u> have non-fixed contamination (e.g. cyclotron bunkers and caves <u>and</u>, cell<u>s</u>, etc.); and-
- c) <u>pP</u>ackages are being prepared for shipment.

Monitoring for Room-aAirborne cContamination Monitoring

9.16.9.15. Typically, there are two methods to assess air<u>borne concentration-contamination</u> [?] in <u>a radioisotope</u> production <u>facilities</u><u>facility</u>: either by <u>using an installed fixedor</u> portable continuous air monitor with a shielded contaminant probe, (CAM)-or by <u>performing taking</u> a Formatted: Space After: 12 pt

grab sample on a filter, <u>and</u> then removing the filter media for measurement at an analytical <u>centre/ location laboratory [?]</u>.

<u>9.17.9.16.</u> Grab sample filters can be fixed or mobile. Achieving a flow rate across a filter at the assumed breathing rate of a worker (for example 20 L/min) normally requires equipment that is too heavy for <u>a-the</u> worker to wear. Personal air samplers, (PAS) which can be worn on a worker's lapel, normally operate at low flow rates (for example 2 L/min) and, are more directly placed in the workers breathing zone, but <u>may-might</u> get covered by the worker's clothing or have <u>issues-a limited with battery life</u>.

<u>9.18.9.17.</u> The following should be considered when establishing the breathing air monitoring programme for monitoring breathing air:

a) Set<u>ting</u> levels at which a room <u>may notis</u> not permitted to be entered \pm or <u>for which</u> respiratory protection <u>must or mayhas to</u> be used \pm <u>Such levels should be</u> based upon filter efficiency, detector efficiency, line losses, pump flow rate and dose conversion factors [31] for inhalation [34]. \pm

b) Place alarming <u>CAMs-continuous air monitors</u> in locations of high risk for intakes of radioactive substances (<u>e.g.</u> radioiodine processing areas, waste, cyclotron<u>or</u> Alinear accelerator bunker-and caves) and have the alarm register at appropriate access location;[last bit not clear can it be deleted?]

c) Ensuring that T the number of bends in tubing for <u>continuous air monitors</u> <u>CAMs needs to</u> <u>beis</u> minimized to avoid line losses. Tubing material for <u>continuous air monitors</u> <u>CAMs needs</u> <u>to should</u> be correctly chosen so that <u>the radioactivitycontamination</u> is minimally deposited on tubing. Tubing <u>runs-lengths</u> to <u>continuous air monitors</u> <u>CAMs must-should</u> be as short as possible.

9.19.9.18. As continuous air monitors CAMs are optimally placed as close as possible to the source of airborne activity, they are frequently placed in radiation fields that vary in intensity over time. Therefore, a significant amount of shielding is necessary to avoid generating incorrect signals due to variations in local background radiation levels caused by movement of products, waste or; raw materials, etc. Otherwise pPackages placed near an insufficiently shielded continuous air monitor CAM-will appear to cause an increase in air activity or mask airborne activityies. If the continuous air monitor CAM-has two detectors, one can be used to correct the variations in the background radiation levels. Filter material should be optimally

placed to adequately filter the aerosols. <u>Examples of F</u>filter materials <u>include_are</u> paper and fiberglass for particulates <u>and</u>, activated charcoal and silver zeolite for radioiodine, <u>etc</u>.

Maintenance and calibration

9.20.9.19. Following calibration of monitoring equipment, a label should be attached to the instrument to provide information, including the organization performing-that performed the test, the test certificate number and the date of the test or the date when the next test is due. Tests should be carried out by an organization that maintains reference radiation fields traceable to national or /international primary standards.

9.21.9.20. Installed Fixed radiation monitoring instruments are not calibrated in the same sense as radiation survey meters. Since their operation is 'pass-fail', fixed-installed instruments should be subject to periodic operational testing to ensure that they retain the capability to respond to relevant radiation levels. For example, check sources can be used on a monthly basis to verify that the a_radiation room monitor responds appropriately. In some applications, such as in using a single channel analyszer for air-offluent-monitoring_of airborne effluents, the instrument should be calibrated periodically to ensure that the detector voltage and window settings are still applicable.

9.22.9.21. Further information on the establishment and operation of calibration facilities for radiation survey instruments and recommended calibration procedures is provided in Ref. [3235].

Records of radiation and contamination surveys

9.23.9.22. Reports on radiation and contamination levels should include the following information:

- Survey date;
- Information on the survey instrument (manufacturer, model number and serial number);
- Calibration date of the survey instrument;
- Correction factors, <u>background</u>-subtraction<u>of background radiation</u>, conversions or other calculations for the survey instrument if used;
- Name of the person performing the survey;

- Radiation levels and the corresponding locations, are best to recorded and communicate on sketches of the section of the building which that was surveyed;[OK?]
- Contamination levels and the corresponding locations;
- Cause of the contamination, if known;
- Any actions taken on the basis of information yielded by the survey.

10. ENVIRONMENTAL MONITORING AND EFFLUENT DISCHARGE

ENVIRONMENTAL MONITORING

10.1. Radioisotope production and processing inherently poses a_risk of dispersal of radioactive materials to the environment, which can be as the primary product or a decay product, which can be as the primary a single radionuclide product-or as a mixture of decay product radionuclides [?]. The environmental monitoring required is normally limited to performing and documenting dose rate surveys external to the controlled area, with the objective to-of_demonstratinge that members of the public are receiving effective doses less than 1 mSv in a year. In some cases, the boundary to-for performing these measurements is within the building. For new facilities, detailed dose rate surveys should be performed, and any deficiencies in design and construction should be corrected until-to ensure that the facility is deemed safe tocan safely operate under the conditions where at which maximum dose rates can-could_occur. Once the facility is in operational, routine environmental dose rate surveys should be carried out continuously regularly [? really continuously (i.e. all the time with no break)?].

10.2. The <u>results of environmental verification monitoring</u> should be periodically confirmed by measurement of groundwater or soil samples for relevant radionuclides.

EFFLUENT DISCHARGE

10.3. The production technology, the adopted practices and the facility design should all aim to control the amount of activity quantities of radionuclides [?] routinely discharged and to minimize the risk of dischargesunplanned radioactive releases [?].

10.4. Effluent discharges for from the radioisotope production facilities facility should be regulated, based on within authorized discharge limits, which should be developed by the operating organization and made subject to approvaled by the regulatory body. The IAEA publication Safety Standards Series No. GSG-9, Regulatory Control of Radioactive Discharges to the Environment [363] provides more detailed guidance on methodology and procedures to develop such authorized discharge limits.

10.5. The effluent streams should be considered carefully prior to planning and construction of the facility. The eEffluents should also be addressed considered when planning and

Formatted: Left

Formatted: Highlight

implementing new production lines, when methods or equipment are changed, or when operating conditions of the facility itself change (<u>e.g.</u> ventilation_<u>and</u>; pressures-<u>ete-</u>).

10.6. Effective means should be <u>available-put in place</u> for <u>containing-confining radioactive</u> releases of <u>activity</u> before they leave the facility. Best practices include in-process means of capturing and securing gaseous, liquid and <u>dispersed-particulate</u> solid waste. Filtration and trapping systems should be designed to be as close as possible to the source production in order to minimize <u>the</u>-unnecessary contamination of ducts<u>and</u>, piping, <u>ete</u>. The handling of the effluent streams should include safe means of removing other hazardous components (e.g. air filters might not only be installed to reduce release of activity into the atmosphere, but also to minimize releases of other toxic chemicals).

MONITORING OF AIRBORNE [?] EFFLUENTS MONITORING

10.7. The IAEA publicationsGSG-9 [3336] and IAEA Safety Standards Series No. RS-G-1.8, Environmental and Source Monitoring for Purposes of Radiation Protection [3437] have established standards for provide guidancerecommendations on monitoring releases of airborne effluents-emissions.

10.8. Quantitative on-line air effluent-monitoring of gases or aerosols in released airairborne <u>[?] effluents</u> should be performed using:

- A well shielded detector which that views is directed at a cross-section of the stack and is oriented not to detect other sources of radiation;
- A well shielded continuous air monitor (CAM) for sampling the stack;
- A gas flow through n gas flow through ion chamber detector <u>Isame detector as in para</u> <u>9.8?</u> or other means for monitoring inert gases, or other means.

However, in all cases a representative sample of the effluent should be taken.

10.9. Off-line measurements should be <u>taken_made_using</u> filters (cartridge <u>filters</u> or <u>otherwiseother types of filter</u>) <u>which_that</u> are replaced daily or weekly (as necessary) and measured.

10.10. If sampling lines are used, the number of bends in <u>the</u> tubing should be minimized to⁴ avoid line losses. Tubing material should be correctly chosen so that the deposition of <u>radioactivity-contamination</u> on tubing is minimized.

Formatted: Left

Formatted: Tab stops: Not at 0.63 cm

10.11. Experimental evidence should sometimes be used to validate sampling systems. One such example is to release an approved <u>activity amount</u> of ¹¹C labelled carbon dioxide (¹¹CO₂) to calibrate systems at <u>PET positron emission tomography</u> facilities.

10.12. The stability of sampling pump <u>flow rates</u> and stack flow rates should be taken into account and variations in such flow rates may need to should [?] be loggedrecorded.

10.13. Other <u>points_aspects that</u> should be considered with respect to monitoring of air<u>borne</u> emissions <u>include</u>:

- (a) The emitted activity is <u>dependent on the product of</u> concentration and <u>the rate of air</u> flow.
- (b) The monitor should be capable of measuring relevant radionuclides <u>at-with</u> sufficient sensitivity.
- (c) The monitor(s) should be shielded from variations in background radiation.
- (d) If several radionuclides are present, they should, if possible, be identified and quantified.

FILTERING OF AIRBORNE EMISSIONS

10.14. All airstreams in the facility that might contain radionuclides should be considered. This could include air from all controlled areas as well as storage areas, target loading and unloading areas and potentially also from areas containing radioisotope generation equipment.

10.15. Air filters should be suitably placed in the ventilation system prior to the release of air from the building. If the filter (e.g. charcoal) is in an uncontrolled area, it should be adequately shielded to minimize the risk of exposure of personnel.

10.16. Corrosive substances (e.g. acids) should not be ventilated through the ventilation system. In such instances adequate scrubbing using appropriate chemicals or water and filtering should be done before release to the environment.

10.17. Filters should be changed on a regular basis (e.g. annually). The frequency of changing might need to be increased if an elevated trend in emissions is observed.

10.18. If radioactive material is produced that cannot be trapped by the air filtration system, abatement systems (e.g. exhaust bags) should be utilized to store the radioactive material until the radioactivity has decayed to background levels.

10.19. Decisions relating to placement of filters, height of stack, ejection speeds and meteorological considerations [38] should take into account occupied areas and worst case scenarios, including the worst case committed dose to the representative person, and the reference to suitable guidelines for this, and possible general dose constraints (typically 1/10 of the annual dose limit for members of the public). Compliance with this dose constraint is the responsibility of the operating organization, and could be part of the authorization for operation.

10.20. Channels, filters and other components should be manufactured from materials that will not be attacked by components of the air stream, nor should they yield unnecessary particle burdens themselves (e.g. they should be manufactured from stainless steel or epoxy coated). Instructions should be provided to workers on avoiding extensive boiling with strong mineral acids, as well as on good practices to minimize corrosion risks from acid fumes (e.g. by means of gas washers or scrubbers).

10.21. Filters that are likely to contain large amounts of radionuclides at any point in time should be located in controlled areas and, if appropriate, also shielded or separated from areas of any occupancy.

10.22. Pressure drops and the integrity of essential filters should be kept under control by suitable measures. The efficacy of filters should be tested regularly.

10.23. Filters should be removable under radiologically safe conditions (e.g. provisions should be made for safely bagging filters).

- 10.24. Practices for the removal of non-filterable contaminants include:
- (i) The placement of filters as close as possible to the source, at points of lowest airflow.
- (ii) The use of activated charcoal filters.
- (iii) The use of acid filters or scrubbers.

10.25. Non-filterable, non-condensable airborne contaminants that should be addressed include:

- (i) Radioactive noble gases;
- (ii) PET cyclotron products, some of which (e.g. ¹³N₂) cannot be removed from the air stream (some other PET cyclotron products, such as [¹¹C]-CH₄ or [¹¹C]-CO₂, [¹⁸F] <u>FCH₃ or [¹⁸F]-F₂ and [¹³N]-NH₃, can be removed from the air stream with suitable chemical traps);</u>
- (iii) Tritium, and some tritiated and ¹⁴C labelled compounds.

10.26. In case such contaminants pose a significant risk to either workers or members of the public, measures should be taken to limit and control the release of such contaminants.

(d) The most efficient way to control the release of contaminants is to contain and trap the contaminants at the source itself using gas bags or traps (liquid nitrogen or cartridges) or to use tank storage for decay (in case of gases from positron emission tomography).

MONITORING OF LIQUID EFFLUENTS MONITORING

<u>10.14.10.27</u>. National, regional and municipal regulations should <u>apply be applied</u> to limit the discharge to liquid effluent streams, in terms of chemical and biological <u>composition materials</u>, suspended solids, radioactivity and other hazards.

<u>10.15.10.28.</u> Liquid effluents should be monitored on-line or <u>a representative</u> samples <u>may should [?]</u> be taken from a delay tank. Procedures should be developed to ensure that the delay tank contents are adequately mixed so that <u>a representative the sample may be taken is</u> representative. If a sub-sample is to be taken from the representative sample (for examplee.g. for liquid scintillation counting), then the sample <u>should</u> also <u>should</u> be agitated to ensure adequate mixing.

MINIMIZING EFFLUENT DISCHARGES

<u>10.16.10.29</u>. In planning-<u>applications</u>, consideration should be given to the confinement of liquid borne <u>activity</u>-<u>radionuclides</u> in case of flooding, pipe ruptures or <u>extensive</u>-fire-fighting with water.

Formatted: No bullets or numbering

Formatted: Left

<u>10.17.10.30.</u> <u>The pP</u>rocess water should be kept and treated separately. Coolants should <u>only</u> be diluted <u>only</u> with inactive water prior to ultimate disposal. Further details on the control of radioactive discharges <u>is are discussed provided</u> in <u>GSG-9</u> the IAEA publication [3336].

10.18.10.31. Water used for washing and cleaning in <u>radioisotope_isotope_</u>production facilities could potentially be contaminated, depending on the nature of the facility. It might be necessary to pipe such waste streams to storage tanks, perhaps for decay, but ultimately for analysis, possible purification and /distillation and/or subsequent <u>release disposal discharge [?</u> <u>surely not disposal?] in</u>to the <u>general</u> environment.

10.19.10.32. Target and accelerator cooling circuits may become radioactive (excluding the short-lived radionuclide ¹⁶N) <u>due_owing</u> to leaching of activated surfaces or from leakages. Therefore, <u>they_cooling circuits</u> should be disposed of only after <u>check of their</u> radioactivity levels are checked.

<u>10.20.10.33</u>. Dedicated piping for possibly contaminated <u>or</u> /radioactive waste water should be <u>put</u> in place. <u>In ease If acceptable</u> low limits can be <u>asen</u>sured <u>under for</u> all operating conditions, <u>waste water can be piped</u> direct<u>ly piping</u> to <u>the main sewer can be</u> recommended.

10.21.–Workers maintaining such draining installations should be properly protected-trained and instructedshould wear-use appropriate personnel protective equipment clothing [?].

FILTERING OF AIRBORNE EMISSIONS [put this section closer to the section on monitoring airborne releases?]

10.23. All airstreams in the facility that might contain activity <u>radionuclides_should be</u>considered before release. This could include <u>air from</u> all of the controlled areas as well as storage areas, target loading <u>and</u>/unloading areas and potentially also <u>from areas containing</u> radioisotope generation equipment.

10.24. Air monitoring [monitoring is the in earlier subsection, right?] filters should be suitably placed in the ventilation system prior to exiting the release of air from the building. If the filter (e.g. charcoal) is in an uncontrolled area, it should be adequately shielded to minimize the risk of exposure to of personnel.

Formatted: Heading 2, Outline numbered + Level: 1 + Numbering Style: 1, 2, 3, ... + Start at: 1 + Alignment: Left + Aligned at: 0 cm + Tab after: 0.63 cm + Indent at: 0 cm, Tab stops: Not at 0.63 cm

Formatted: Not All caps

Formatted: No bullets or numbering

10.25. Corrosive substances (e.g. acids) and air from areas containing corrosive substances [OK?] should not be ventilated through the air monitoring controlventilation [?] system.

10.26. The fEilters in the filtration system should be changed on a regular scheduled basis (e.g. annually). The frequency of changinge may <u>might_need</u> to be increased if an elevated trend in emissions is observed.

10.27. If radioactive materials are <u>is</u> produced that cannot be trapped by the air filtration system, abatement systems (e.g. exhaust bags) should be utilized to store <u>the</u> radioactive materials until they the radioactivity hashave decayed to background levels.

10.28. General principles of <u>Decisions relating to placement of filters</u>, height of stack, assured <u>JOK to delete?</u>] ejection speeds and meteorological considerations [3538] should take into account occupied areas and worst case scenarios, <u>including</u> the need for calculation of worst case committed radiation dose to <u>the</u> most exposed member of the public, and the reference to suitable guidelines for this, and possible general dose constraints (typically 1/10 of the annual dose limit to <u>for</u> members of the public). Compliance with this <u>dose constraint [or with the</u> <u>dose limit?</u>] is the responsibility of the facility operatoroperating organization, and could [should?] be part of an operation permitthe authorization for operation.

10.29. Channels, filters and other components should <u>be manufactured from materials that</u> <u>will [correct meaning?]</u> not be attacked by components of the air stream, nor <u>should they yield</u> unnecessary particle burdens by themselves (e.g. they should be manufactured from stainless steel or epoxy). Instructions should be provided to workers on avoiding [pls check meaning] Description of the abundant use of <u>extensive_boiling</u> with strong mineral acids should be included, as well as <u>on_good</u> practices to minimize corrosion risks from the acid fumes (<u>e.g.</u> <u>by means of gas_washers_or/scrubbers)</u>.

10.30. Filters bound that are likely to contain <u>collect [?]</u>large activities <u>amounts of</u> <u>radionuclides</u> at any point in time should be placed <u>located</u> in controlled areas and, if appropriate, also shielded or separated from areas of any occupancy.

10.31. Pressure drops and the integrity of critical essential [pls check meaning] filters should be kept under control by suitable measures. <u>Ways of testing the The efficacy of such filters</u> should be tested regularly.[meaning?]

Formatted: Highlight

Formatted: Highlight

10.32. Filters should be removable under radiologically safe conditions (e.g. provisions should be made for safely bagging filters provisions).

10.33. Practices for the removal of non [???]filterable contaminants may include:[is this a correct list of bullets? does it have to do with non-filterable contaminants or filterable contaminants?]

(xxxiv) The Pplacement of filters as close as possible to the source, at points of lowest airflow.

(xxxv) The Uuse of activated charcoal filters.

(xxxvi) The Uuse of acid filters or /scrubbers.

(xxxvii) Pressure drops and integrity of critical filters should be kept under control by suitable measures.[repeat of para 10.30]

(xxxviii) Ways of testing the efficacy of such filters.

10.39. Considerations concerning nNon filterable, non condensable airborne contaminants that should be addressed include:

() Radioactive noble gases.;

() Some PET cyclotron products, some of which (e.g. example $^{13}N_2$) cannot be removed from the air stream. (Some of the other PET cyclotron products, such as [^{14}C] CH₄ or [^{14}C]-/CO₂, [^{18}F] FCH₃ or [^{18}F] F₂ and, [^{13}N] NH₃₂ can be removed from the air stream with suitable chemical traps);.

10.43. In case such contaminants pose <u>a</u> any significant dose risk/contribution to either workers or members of the public, measures should be taken to limit and control the release of such contaminants.

10.44.<u>10.34.</u> The most efficient way to control the release of contaminants is to contain⁴ and trap the contaminants at the source itself with using gas bags or traps (liquid nitrogen or cartridges) or to use tank storage for decay (in case of the gases from PET positon emission tomographygases). Formatted: Tab stops: Not at 0.63 cm

Formatted: Indent: Before: 0 cm

68

11. PERSONAL PROTECTIVE EQUIPMENT

11.1. The operating organization should ensure that engineering controls are in place to protect workers from exposure <u>due</u> to radioisotopes and other associated hazards. In some <u>cases</u>, <u>eE</u>ven when optimized engineering controls have been implemented, additional protective measures such as personal protective equipment (<u>PPE</u>) should will need to [not really a should with 'in some cases' at the beginning <u>so either delete 'in some cases' or change should to 'will need to'</u> be used to keep radiation doses as low as reasonably achievable or to mitigate the consequences of an accident.

11.2. The operating organizsation should ensure that workers are provided with suitable and adequate <u>personal protective equipment PPE</u> which that meets relevant standards and specifications. According to GSR Part 3 [3], the operating organization is required to <u>provideensure that personal protective equipment PPE is provided</u> to workers. The Personal protective equipment PPE is provided to workers.

- (a) Protective clothing, including gloves, overalls and caps for contamination hazards;
- Protective respiratory equipment suitable to for protecting the respiratory tract from the contamination hazards;
- (c) Protective aprons and gloves and organ shields for external radiation hazards;
- (d) Safety glasses or face shields for <u>splash</u>-protection<u>against splashes</u> involving <u>radiological</u>-radioactive [?] liquids_material_and /potential protection_against beta radiation or-and leaded glasses for <u>protection against</u> external radiation hazards.
- 11.3. The Personal protective equipment PPE for emergency operations may include:
- (a) Full Filled [?] Full body covered air suits with air lines or breathing apparatus for entering contaminated areas:
- (b) Lead aprons, critical organ protectors and gloves for handling situations with high dose rates.

11.4. Where appropriate, [why where appropriate?] wW orkers should receive adequate training and refresher training in the use of personal protective equipment PPE. All personal protective equipment PPE should be maintained in working order and, tested at regular

intervals.<u>if appropriate and be maintained for use in the event of usage.[same as 'maintained</u> in working order'?]

11.5. The reliance on <u>personal protective equipment PPE</u> for protection and safety should be minimizsed by the operating organiszation during normal operations by <u>providing means of</u> appropriate protective measures and safety provisions, including well engineered controls and satisfactory working conditions.

11.6. The safety assessment should provide information for the job specification for each area and process. An employment medical examination which is carried out for health surveillance purposes, should be used to determine if whether a person-worker is medically fitcapable of safely-to-usinge the prescribed personal protective equipment PPE for the job. Some of the Aaspects to be covered for such medical examinations are-include the possibility of impaired or reduced lung function, allergies, claustrophobia and hypertension, for example, that which cwould limit the use of some of the personal protective equipment PPE.

11.7. Contaminated re-usable <u>personal protective equipment</u>, <u>PPE like-such as expensive</u> <u>[why expensive? you've already said it's re-usable] apparels clothing [?]</u> and <u>washed [why</u> <u>washed?]</u> overalls, should be <u>left to</u> decayed, and if necessary, decontaminated in a decontamination room. Highly contaminated <u>personal protective equipment</u> <u>PPE</u>-should be left to decay before sending for washing. In cases where long-lived radionuclides are present, the <u>radiation protection officer RPO</u>-should decide <u>if</u> whether <u>it</u>-such personal protective equipment <u>can-needs to</u> be considered as radioactive waste.

11.8. If the use of <u>personal protective equipment PPE</u>-is being considered for a task, any additional exposure that could result owing to the additional time or inconvenience, and any additional non-radiological risks, should be assessed against <u>the risks associated with</u> performing the task without using <u>personal protective equipmentPPE</u>.

12. NUCLEAR SECURITY CONSIDERATIONS

12.1. The <u>nuclear</u> security policy of the organization should aim to deter, detect, delay, and respond to any attempt to gain or actual unauthorized access to radioactive sources. The following paragraphs are intended to raise awareness about the <u>nuclear</u> security issues that need to be addressed. <u>Such issues-and which</u> are covered in detail in the IAEA Nuclear Security Series (NSS) of publications. In particular, <u>IAEA Nuclear Security Series NSS-No.</u> 14 [56] provides recommendations to States and competent authorities on how to develop or enhance, to implement, and to maintain a nuclear security regime for radioactive material, associated facilities, and associated activities. <u>IAEA Nuclear Security Series NSS-No.</u> 11 [67] contains more specific guidance to assist States in the development of regulatory requirements for the security of radioactive sources. <u>IAEA Nuclear Security Series NSS-No.</u> 9 [78] provides guidance on the security of radioactive material during transportation.

12.2. <u>Nuclear sSafety measures</u> and security measures have <u>the_in_common the_aim</u> of protecting human life_and, health, <u>society</u> and the environment. Safety measures and security measures should be designed and implemented in an <u>coordinated_integrated</u> manner so that security measures do not compromise safety and safety measures do not compromise security.<u>[wording lined up with agreed generic text in SPESS C]</u>

12.3. To ensure that safety <u>measures</u> and security <u>measures</u> are implemented in a compatible manner, the government may have designated a responsible body for managing the interfaces between safety and security in relation to radioactive sources. This <u>may_might</u> be the regulatory body if the regulatory body has responsibility for both the safety and security of radioactive sources under the regulatory infrastructure.

12.4. In radioisotope production, there may be an interface between security and safety measures with regard to access to information. For safety purposes, information on the locations and characteristics of radioactive sources and the safety measures in place may need to be readily accessible. However, this information may also be of potential value to an adversary, and therefore security considerations may require that the confidentiality of some sensitive information be protected. [one protects information; one doesn't protect the confidentiality of information] Guidance on the protection and confidentiality of sensitive information in nuclear security is provided in IAEA Nuclear Security Series NSS-No. 23-G [89]. An appropriate balance needs to should [surely this can be a should! it's really on the

<u>interface</u> be maintained between the availability of information for safety reasons and the need to protect sensitive information for security reasons.

12.5. Safety measures designed to prevent the loss of radioactive sources or for protection <u>of</u> <u>people from-against</u> radiation <u>incidents-exposure</u> can also provide some benefit <u>in protection</u> against the theft of <u>those-such</u> sources. For Category 4-<u>to</u>5 sources, for example, it is recommended that measures described in GSR Part 3 [3] <u>are-be</u> used. However, the element of intent involved in unauthorized access means that additional considerations apply for higher activity sources (Category 1 to 3), and additional and/or different security measures may be <u>needed necessary</u> to protect against unauthorized access.

12.6. The IAEA Nuclear Security Series (NSS)-provides guidance on how to define the requirements for the security of radioactive sources using a graded approach, based on considerations of threat, the nature of the sources, and the relative attractiveness of the material for use in a malicious act. <u>IAEA Nuclear Security Series NSS-No. 11 [67]</u> suggests using the IAEA's categorization system in order to assign a particular security level to sources and to help define the necessary security measures. Radioisotope production sources are typically assigned to Security Level C, and not higher than Security Level B. The security measures required for each security function for Security Levels B and C are described in detail in <u>Ref. [67]</u>.

12.7. It should be noted that, dueDue to their small size_and, portability-and the fact they are most often used far from any secure facility [this could imply that an isotope production facility is not secure], radioisotope sources may need additional security measures or procedures to ensure they remain adequately protected and under control both-during use, during transport incidental to their use, and while they are not in use. The specific details of such additional measures will depend on the threat assessment. Reference [67] also-contains illustrative security measures, including those-measures for mobile operations where measures applicable to a fixed installation are not practicable, which can be adapted for mobile <u>Security Level</u> C operations.

13. TESTING AND MAINTENANCE OF EQUIPMENT AND RECORDS IL DON'T-THINK YOU CAN TEST RECORDS

13.1. To ensure the continued safe operation of the <u>radioisotope radiation</u>-production facility, the operating organization should set up a formal programme of maintenance and testing to test all safety functions regularly, <u>as follows:</u>. The following actions should be performed periodically (or as otherwise specified below):[no need for a should in the chapeau and thena gain in the bullets]

- (a) Particular attention should be paid to regular testing of components of the safety interlock system for correct operation, in accordance with the instructions of the equipment manufacturer. These tests should be carried out by appropriately qualified persons and endorsed witnessed by with adequate information to the radiation protection officerRPO.[change to make consistent with para 13.6, pls check]
- (b) Periodic leak tests of radioactive sources should be carried out in a manner and at a frequency as recommended by the source supplier and in accordance with regulatory requirements.

PERIODIC TESTS

13.2. The ventilation system (buildings, hot cells, fume hoods) should be maintained on a regular basis (<u>at least annually</u>).

13.3. The heating and _cooling systems, generators, radiation monitoring equipment, interlocks, freezers, building monitoring system, HEPA filters in clean rooms and dose calibrators should be maintained on a regular basis. All equipment used in measuring radiation levels and₇ weights, as well as other equipment_and_as required by the regulatory agencies-body, should be tested, calibrated/ and maintained on a regular basis.

- 13.4. The following additional tests should be carried out on a monthly basis:
- (a) Check, in accordance with the manufacturer's instructions, that access to the facility is prevented when the radiation monitor alarm sounds. Check the emergency exit procedure by ensuring that the personnel access door can be opened from the inside and that other means of exit in an emergency are <u>operating-functioning</u> properly.

- (b) Check all visual warning signals and alarms for correct operation. Check all control indicator lights to ensure that they illuminate.
- (c) Verify that <u>all_the</u> uninteruptible power supplyies (UPS)⁹ are_is_functioning within specification. It is a good practice to use an <u>uninteruptible power supply UPS</u> as a backup power supply for the cyclotron <u>or</u> Alinear accelerator control system, as power failure can affect the operation of control units.
- (d) Verify the proper operation of that the heat detectors and smoke detectors are functioning properly.
- (e) Verify all safety interlocks on removable shield plugs (or self shield) in the cyclclotron room.
- (f) Verify that posted notices are in place and that all the details are correct.

13.5. If any of the checks indicate a fault or that a safety interlock is not functioning properly, the facility should not be operated until the system has been returned to <u>its_a</u> validated <u>operational_safe</u> state.<u>[OK? not sure what its validated operational state is, especially when</u> <u>read together with next sentence]</u> The return of the facility to normal operation should be subject to approval by <u>a the radiation protection officerRPO</u>.

RECORDS

13.6. The results of all tests described above should be recorded on a formal checklist signed by a the radiation protection officer RPO who has witnessed the tests.

13.7. <u>The mM</u>aintenance records should be kept for such periods of time as are prescribed by the regulatory body.

13.8. Records should be kept of the radioisotope inventory, and of information on the storage and radioisotope transfer information of radioisotopes.

FACILITY MAINTENANCE AND MODIFICATION

13.9. Maintenance operations at the facility should be coordinated with the manufacturer of the various <u>pieces_items_</u>of equipment in the facility to ensure that appropriate repairs,

Formatted: Left

⁹ An uninterruptible power supply is a backup power supply that, in the event of power failure or power fluctuations, allows enough time for an orderly shutdown of the system or for a standby generator (\Rightarrow) to start up.

modifications and system upgrades are completed as perin accordance with approved protocols.

13.10. Bypassing or disabling a safety interlock should be done only with the express, written approval of <u>a-the radiation protection officerRPO</u>. All circumstances necessitating any component of a safety interlock to be bypassed or disabled should be documented with a description of the circumstances and the actions taken, and with the specific approval of a-the radiation protection officerRPO.

13.11. If it becomes necessary to bypass or disable a safety interlock, independent verification should be obtained that the accelerator is not onswitched off (e.g. the ion source is not on <u>[what does 'the ion source is not on' mean? the ion source being in the shielded position, maybe?]</u>). The affected component of the safety interlock system should only be bypassed or disabled only long enough to allow entry to the radiation room to remedy the problem (e.g. to repair or replace the monitor), during which time the relevant portion of the facility will not be in operation. Entry to the radiation room should be permitted once a satisfactory survey of the area has been completed.

13.12. If it is necessary to bypass or disable a component of a safety system, the affected component should be tested for specified-proper operation upon being reinstated. The specific test will depend on which component is to be tested, but the test should be a duplicate of the routine test performed to verify specified-proper operation. After verifying that the safety interlocks have been restored to their design function, approval of a the radiation protection officer RPO-should be obtained for a return of the facility to normal operations.

13.13. Since bypassing or disabling any component of the safety interlock system is to be avoided, except under abnormal circumstances, routine and preventive maintenance functions should be designed to prevent the <u>necessity_need</u> for bypassing safety interlocks.

14. RADIOACTIVE WASTE MANAGEMENT AND DECOMMISSIONING

14.1. The <u>rRegulatory bBody should_is required to</u> establish requirements and criteria for radioactive waste <u>management [32]</u>. Radioactive waste is radioactive material for which no further use is foreseen and with characteristics that make it unsuitable for recycling or authorized discharge. This may include unsealed and sealed sources [33<u>36</u>, <u>396</u>]. Radioactive waste should be <u>examined_addressed</u> in the safety assessment prior to its generation <u>and needs</u> to have considered <u>Nnon-radiological hazards</u> (e.g. biohazards <u>and</u>, chemical <u>contenthazards</u>) and <u>the need</u> to meet the acceptance criteria of the ultimate waste destination (e.g. <u>a</u> national waste <u>sitedisposal facility or</u>; interim storage site) <u>should be also considered</u>.

14.2. Radioactive waste is generated at <u>certain_various</u> points in a radioisotope production facility. Low_level waste is <u>created_generated</u> from contamination control procedures (e.g. disposable <u>personal protective equipmentPPE</u>, clothes_<u>121</u>, packages <u>and</u>, surface and floor swipes, <u>etc.</u>). The waste with the highest activity concentration is generated from activated materials within the cyclotron_or_flinear accelerator, targets, synthesis processes and quality control testing. Archive samples and unsold products are other examples of waste.

14.3. Application of waste management protocols, clearance of materials after processing, <u>decay</u> storage for decay, and reuse and recycling of material can be effective in reducing the amount of radioactive waste that requires disposal. In accordance with para. 4.9 of IAEA Safety Standards Series No. GSR Part 5, Predisposal Management of Radioactive Waste [32], Tthe operator has tooperating organization is required to ensure that these processes are in compliance with the conditions and criteria established in regulations or by the regulatory body. The regulatory body also hasis also required to ensure that the operator operating organization gives due consideration to non-radiological hazards in applying such options [324].

14.4. The control measures are generally applied in the following order: reduce waste generation, reuse items as originally intended, recycle materials and, finally, consider disposal as radioactive waste.

14.5. In <u>line-accordance</u> with Requirement 10 of <u>IAEA Safety Standards Series No.</u> GSR Part 6, <u>Decommissioning of Facilities</u> [3740], the <u>operating organization production facility</u> is required to prepare a decommissioning plan (<u>'from the cradle to the grave'</u>) for their the facility <u>which-that considers the</u> ultimate disposal of all resultant waste₇ and contaminated

and/or activated equipment and materials, including an estimation of cost, <u>identification of the</u> provision of financial resources and assurances to cover the cost associated with decommissioning. This decommissioning plan is required to be periodically reviewed and updated as necessary in the light of <u>operational-operating</u> experience gained, new or revised safety requirements, <u>available</u>-lessons learned from the decommissioning of similar facilities, and technological developments relevant to decommissioning [<u>3639</u>].

14.6. The production facility may possess <u>S</u>scaled sources in use at the radioisotope production facilitythat will, in time, become spent or disused sealed sources. They then need to have an approved A disposal pathway should be established, subject to the approval of the regulatory body, so that sealed sources do not become orphaned. The accounting of sealed sources should follow-meet the requirements of the regulatory body.

14.7. Some <u>radioisotope</u> production facilities fabricate sealed sources and the radioactive material <u>in such facilities</u> is typically in one of three states: raw material, finished product (inventory) or waste. <u>These-The operating organizations of such radioisotope</u> production facilities should offer their customers a disposal pathway as a pre-sale condition. The <u>operating organization production facility</u> is responsible for accounting for their sealed sources, and <u>for documenting returned</u>, spent customer sources to <u>document ensure</u> that the sealed sources <u>have not beendo not become</u> orphaned.[<u>pls check meaning of this]</u>

14.8. The <u>operating organization production facility</u> should provide <u>the regulatory body with</u> <u>[to whom should this list be provided?]</u> a list of anticipated waste streams and sources to be generated at the facility, including waste forms (e.g.; solid, liquid and/or gaseous), estimates of waste volumes, waste categories and plans for storage and disposal.

CHARACTERIZATION OF RADIOACTIVE WASTE

14.9. At <u>a</u>radioisotope production <u>facilities_facility</u>, aqueous waste results from chemical processing, mainly the etching and dissolving of target materials. The Such waste should only be processed <u>only</u> after its precise characterization. In addition to its radiological, physical, mechanical, chemical and biological properties, radionuclide impurities from the production process should be characterized and segregated. Radionuclide impurities in the waste streams <u>shall_should_first</u> be estimated from predictive models and then measured. Radioactive materials that <u>are is produced in cyclotrons or flinear accelerators</u> can contain small quantities of <u>longer lived</u>-radioisotope impurities that are longer livedother than the finished product.

The <u>operating organization of the radioisotope</u> production facility (in consultation with <u>the</u> <u>operating organizations of the</u> waste disposal facilityies) is responsible for developing <u>and</u> <u>applying following</u> the waste acceptance criteria <u>for disposal</u> for approval by the regulatory <u>body.[is the operator of the radioisotope production facility really responsible for developing</u> the acceptance criteria? I assume it's the acceptance criteria for disposal we're talking of here]

14.10. The <u>operating organizationproduction facility</u> should <u>follow-meet</u> the clearance criteria established by the regulatory body. Clearance levels establish at which point material under regulatory control can be removed from this control [<u>3841</u>].[<u>I think RS-G 1.7 is a better</u> reference here than <u>GSR Part 5</u>] In order to demonstrate that the quantity or concentration of radioactive substances in the material <u>in their possession are is</u> below the clearance level, the <u>operating organization production facility</u> should first <u>establish-determine</u> the radioisotopes in the waste streams, and then compare their activity concentrations with the clearance levels. The activity concentrations in waste streams can be determined by <u>understanding-taking</u> the initial concentrations and calculating for decay and/or by directly measuring and identifying the activities of the radionuclides present. The <u>operating organization production facility</u> should document this evaluation.

PRINCIPLES OF WASTE MINIMIZATION IONLY SF-1 CONTAINS PRINCIPLES

14.11. Waste mMinimization of the amount of waste generated is an-important step infor waste management and for controlling potential-risk as well as cost. The principles of 'delay Delay and decay'₇ and 'concentrate and contain' [39] are important intwo of the principal approaches to waste minimization [32].

14.12. Segregation is an important <u>concept_step</u> in waste minimization within the controlled area. Waste should be first segregated into two categories: waste that is known<u>to be</u> or is suspected of being radioactive, and waste that is believed to be non-radioactive<u>under the clearance levels</u>. The latter category<u>It</u> should be verified <u>that the latter category to</u> meets the clearance criteria.

14.13. Another form of <u>S</u>segregation is <u>also applied to for</u>-biological waste that needs to be treated (by <u>either</u>-autoclaving, sterilizing or incinerating) or <u>to</u> liquids that <u>may requirenced</u> chemical treatment (e.g.; <u>to maintain an alkaline pH value important</u> for radioiodine <u>and must</u> remain alkaline)[<u>pls check brackets in context of whole sentence]</u> for safe storage, transport or disposal.

HANDLING AND PROCESSING OF RADIOACTIVE WASTE

14.14. Depending on local-regulatory approval, it may be acceptable to 'dilute and disperse' [40]-radioactive material [32]. An example of the use of 'dilute and disperse' might involve a filtered ventilation exhaust where the activity concentrations of gaseous-airborne [?] effluents concentrations that have been pre-determined (by-in accordance with regulatory approval) not to endanger people or the environment. Liquid waste should be safely stored in proper storage tanks, contained and subsequently-consolidated [consolidated with what? (consolidated means combined) or do you mean solidified/vitrified?] for ultimate disposal treated and disposed.

14.15. The <u>facility operatoroperating organization</u> <u>should fis required to?</u> ensure that radioactive materials and <u>sources [normally not used in this way]</u> from authorized practices are is not discharged to the environment unless: [reworded below in line with DS442, pls check]

- (a) Such discharges is are within the limits specified in the licence and is carried out in a controlled manner [the definition of discharge indicates it is carried out in a controlled manner] according to the regulation in force and the authorization for discharges issued by the regulatory body methods; or
- (b) The exposures due to the discharge are excluded from regulatory control or the discharges can be exempted from the requirement for an authorization activity discharged is confirmed to be below clearance or other disposal levels established by the regulatory body.

14.16. Control measures for the release handling and processing [?] of radioactive materialswaste may include: ssampling of each batch of waste prior to its removal from control. If, in accordanceing with to the national policy and strategy, radioactive waste is to be stored in a centralized storage facility, the operating or ganization should adopt provisions to ensure the prompt transfer of above-waste and disused sources to that facility.

() Sampling of each batch of waste prior to removal from control.
 () If, according to the national policy and strategy, radioactive waste is to be stored in a centralized storage facility, the operator should adopt provisions to ensure the prompt transfer of above waste and disused sources to that facility.

OTHER HANDLING GUIDELINES[DO YOU NEED THIS HEADING?]

Formatted: Left

Formatted: Indent: Before: 1 cm, No bullets or numbering

Formatted: Left

79

<u>14.20,14.17.</u> Other <u>handling</u> guidelines for <u>handling</u> radioactive waste in a radioisotope production facility include the following:

- Radioactive waste <u>is-should be</u> characterized in terms of its physical, mechanical, chemical, radiological and biological properties.
- Containers for solid wastes should be lined with a durable plastic bag that can be sealed (e.g. tied with plastic adhesive tape or heat-sealed with a radio-frequency welder).
- If drums of waste are to be compacted at the <u>radioisotope</u> production facility, the compactor <u>shall_should</u> be enclosed to prevent the spread of contamination. <u>The safety of the c</u>Compactor <u>safety must_should</u> be evaluated to avoid <u>any 'pinch points' or the use</u>, compacting material <u>for compactor material???</u>] which that could damage the drum, etc.
- Sharps should be collected separately and stored in rigid, puncture-resistant containers that have been clearly labelled 'sharps'.
- Refuse cans with lids should be lifted by foot pedals to minimize contamination.
- Liquids <u>can requiremight need</u> chemical <u>adjustment-treatment</u> (e.g.; to <u>maintain an</u> <u>alkaline</u> pH <u>important_value</u> for radioiodine<u>must remain alkaline</u>) and immobilization prior to transport.
- Special precautions may be required might be necessary for on used target foils, target blanks, target bodies and collimators. The area where target reconditioning is performed needs to should be shielded to protect the worker operator's whole body and extremities.

ON-SITE STORAGE OF RADIOACTIVE WASTE

<u>14.21,14.18.</u> In most <u>radioisotope</u> production facilities, it <u>is-will be</u> necessary to have a dedicated <u>storage room for</u> waste and contaminated equipment <u>storage room</u>. Access to this room should be secure and ventilated. <u>In Ssome radioisotope</u> production facilities, <u>place</u> sealed waste containers <u>are placed</u> in air sampling boxes to ensure <u>that</u> there is no airborne <u>radioactivity-contamination</u> present prior to disposal.

14.22.14.19.Routine eContamination and dose rate surveys should be performed carriedout routinely in the storage room. An alarming continuous air monitor and respiratoryprotection may might also be used to control internal exposures in this room.

<u>14.23.14.20.</u> Waste storage locations should be planned and designed to minimize <u>the</u> <u>need for handling and</u>, transport and <u>potential doses to members of exposure of</u> the public (if the storage room is external to the building).

PREPARATION OF WASTE SHIPMENTS

14.24.14.21. It should be ensured that Rradioactive waste should be prepared by the production facility to ensure that it is in a safe and passive form (with regard to radiological, physical, chemical and biological hazards) before it is placed in an approved transport container to be transferred to the a centralized waste storage facility. Waste acceptance criteria for the This_storage facility should be consulted to met_determine_regarding the acceptability of what type of packages, package contents and configurations-are acceptable to be received by them. If the production facility desires to design, build and test [17] a new waste container, such container has to be compatible with the handling capabilities of the centralized waste storage facility.[do you need this? and I don't think the reference of GSG-13 is correct anyway]

<u>14.25.14.22.</u> All floor drains and sinks should discharge into delay<u>tanks</u> or *A*holding tanks and <u>water</u> <u>quality</u> <u>including</u>-activity concentrations in the <u>runoff should be</u> monitored <u>prior to disposal</u>. The discharge port of the main floor drains should have a removable bladder type plug to contain the <u>spilled</u>-liquid in the <u>drain pipesdrainage system</u> until it has been assessed for disposal.

14.26.14.23. The contents recommendations provided in of section 16 equally also apply to waste shipments and should be observed.

<u>14.27,14.24.</u> . The operating organization should verify that the recipient has an Aauthorization or a regulatory permit to receive the radioactive waste should be required for facilities where the radioactive waste will befor storageed/ or disposal.ed.

15. TRANSPORT OF RADIOACTIVE MATERIAL

TRANSPORT REQUIREMENTS

15.1. Transport of radioactive materials should conform to national regulations inside with the State and to the IAEA regulations for international transport Transport Regulations [202].

Movement of radioactive material within the worksite

15.2. When radioactive materials and sources are to be moved within a site for <u>radioisotope</u> production operations, they should be kept in the storage facility until they are <u>ready</u> to be moved to the new location.

15.3. The <u>sS</u>ources should be moved only in shielded containers, and these should be locked and the keys <u>should be</u> removed <u>and held only by authorized personnel</u>. If a vehicle or trolley is <u>to be</u> used to move the container, <u>it-the container</u> should be securely fastened inside <u>the a</u> separate compartment of the vehicle <u>or trolley</u>. The shielded container should be kept under surveillance for the duration of the movement on the <u>work</u>site. <u>The keys of the container</u> <u>should be kept by the authorized person</u>.

Transport to another site

15.4. When radioactive materials <u>are is</u> to be transported from the <u>radioisotope</u> production facility to another location, they it should be kept in the storage facility until they are it is <u>ready</u> to be moved to the new site.

15.5. The <u>sS</u>ources should be moved only in shielded containers, and these should be locked and the keys <u>should be</u> removed. The operating organizations should ensure that the transport and the transport packages comply with the IAEA <u>Transport_Regulations</u> for the <u>Safe</u> <u>Transport of Radioactive Material [22</u>0] or equivalent national or international regulations.

15.6. Where applicable, consideration should also be given to binding international instruments for specific modes of transport, such as by air [42+] and by sea [432].

15.7. Regional agreements such as the European Agreement Concerning the International Carriage of Dangerous Goods by Road (ADR) [4<u>4</u>3], the European Agreement Concerning the International Carriage of Dangerous Goods by Inland Waterways (ADN) [4<u>5</u>4] and the Agreement of Partial Reach to Facilitate the Transport of Dangerous Goods, signed by the

Governments of Argentina, Brazil, Paraguay and Uruguay (MERCOSUR/MERCOSUL) [465] may-might also apply.

<u>15.8.</u> The IAEA Transport Regulations [2022] assign responsibilities for individuals involved in the transport of radioactive material:

- (a) <u>T</u>the consignor (a-the person, organization or government that prepares a₄ consignment for transport);₇
- (b) <u>t</u>The carrier (the person, organization or government that undertakes transport of radioactive material):<u>and</u>-
- (c) **The consignee (the person, organization or government that receives a consignment).**

15.8. In some cases, for an operating radioisotope production facility, the operating organization <u>will</u> performs all three functions and <u>as such</u> is required to discharge the responsibilities associated with each function.

15.9. Transport of radioactive material is a complex activity, and a comprehensive overview of the relevant requirements-IAEA Transport Regulations [22] is outside the scope of this Safety Guide. Guidance on how to meet transport related these requirements is provided in IAEA Safety Standards Series No. SSG-26, Advisory Material for the IAEA Regulations for the Safe Transport of Radioactive Material (2012 Edition) [476].

<u>15.10.</u> Comprehensive recommendations guidance on nuclear security in the transport of radioactive material are is provided in <u>Ref. [78]</u>.

Formatted

Formatted: No bullets or numbering

Formatted: Normal, Line spacing: single, No bullets or numbering, Tab stops: Not at 1.25 cm

16. EMERGENCY PREPAREDNESS AND RESPONSE

GENERAL	Formatted: English (United States)
	Formatted: Heading 2
16.1. According to GSR Part 3 [3] and GSR Part 7 [13], anAn emergency is	Formatted: English (United Kingdom)
<u>"aA</u> non-routine situation that necessitates prompt action, primarily to avoid or to mitigate a hazard or adverse consequences for human <u>life</u> , health-and safety, quality of	Formatted: Indent: Before: 1 cm, No bullets or numbering
life, property or the environment.	
This includes nuclear <u>or and</u> radiological emergencies and conventional emergencies such as fires, release of hazardous chemicals, storms or earthquakes.	
such as mes, release of nazardous chemicals, storms of carinquakes.	
16.1. It-This includes situations for which prompt action is warranted to mitigate the	
adverse effects of a perceived hazard."	
16.2. As defined in GSR Part 3 [3] and GSR Part 7 [153], a nuclear or radiological emergency	
is <u>:</u>	
16.2. <u>"aAn</u> emergency in which there is, or is perceived to be, a hazard due to:	Formatted: Indent: Before: 1 cm, No bullets or numbering
(a) The energy resulting from a nuclear chain reaction or from the decay of the	Formatted: Indent: Before: 1.9 cm, Hanging: 0.63 cm
products of a chain reaction; or	
(b) Radiation exposure."	
(b) Radiation exposure	
16.3. Incidents and accidents at a radioisotope production facility can occur mainly as a result	
of operator error or equipment failure and may lead to a radiological emergency. Typical	
incidents and accidents-include: (1)-	
incluents and accidents include. (1)	
<u>— Breach of a target package breach;</u>	Formatted: Bulleted + Level: 1 + Aligned at: 0.5 cm + Indent at: 1.14 cm
<u> (2) hAbnormal or Hh</u> igher dose rate than expected fis this really an incident, or a	
consequence of an incident?]; (3)-	
<u> </u>	
<u>A</u> leaking source; (5) f	
<u>Fire inside the hot cell, ℓ clean rooms or ℓ other production areas;</u>	

- <u>(6) A loss of supply air to the facility and/or a loss of exhaust air from the hot cells;</u> (7)-
- <u>---bB</u>reakage of the cooling line for the cyclotron and the targetary transfer [?] system and consequent flooding in the facility; (8)
- <u>A natural disasters</u> (e.g. <u>a hurricane</u>) affecting the facility; and (9)
- **16.3.** <u>A</u> nuclear security events resulting in <u>a</u> loss of control <u>over-of</u> radioactive material or <u>of</u> the facility, such as theft <u>or sabotage</u> of radioactive material <u>or sabotage</u>.

16.4. The hazards associated with the operation of a radioisotope production facility and the potential-consequences of a <u>nuclear or</u> radiological emergency are required to be assessed as a means to provide a basis for establishing <u>adequate-emergency</u> arrangements-for-emergency preparedness and response [1315, 4548]. Potential eEmergencies that could affect workers, <u>members-of-</u>the public or the environment and could warrant emergency response actions should be identified in the <u>operating organization's-</u>hazard assessment <u>for the radioisotope production facility [1314, 4748]</u>.

16.5. Based on the assessed hazards and the potential consequences, emergency arrangements for the radioisotope production facility should be established for the radioisotope production facility in accordance with Refs [498–510]. Radioisotope production facilities generally fall into emergency preparedness category III, as set outdescribed in <u>GSR Part 7 [153, 48]</u>. Emergency arrangements that correspond to this category should be established for preparedness and response for a radiological emergency involving the radioisotope production facility. Some radioisotope production facilities may pose limited hazards on-site and off-site hazards. However, addressing the perceived hazards or other non-radiological hazards in these circumstances may warrant implementing parts of emergency arrangements.

16.6. The applicability of <u>various sections paragraphs of in</u> GSR Part 7 to <u>facilities in</u> <u>Ee</u>mergency <u>Pp</u>reparedness <u>Cc</u>ategory III is <u>listed set out</u> in the <u>Ttable in a</u>Annex 1 to GSR Part 7 [15] and these should be used during the preparation of <u>emergency EPR</u>-plans for the <u>radioisotope production</u> facility.

EMERGENCY PLANS AND PROCEDURES

16.7. Although <u>the prevention</u> of incidents and accidents is the first line of defence, emergencies events could still may occur that would necessitate protective actions or other Formatted: English (United States)
Formatted: Heading 2

response actions. The Ooperating organizations is are required to have in place an emergency plan and procedures developed at the preparedness stage [13]prepared in advance, so as to be able to for the goals of emergency response to be achieved and for the emergency responsed to be effectively to an emergency involving the facility under their responsibility [15]. [Hanguage of GSR Part 7 paras 6.19 and 6.20]

16.8. An outline for a facility (on-site) emergency plan <u>can be found in Ref. [4950]</u>; <u>that-this</u> should be used for developing <u>an-the</u> emergency plan <u>of-for</u> the radioisotope production facility. <u>can be found in Ref. [49]</u>. Notices outlining the <u>procedures for</u> notification <u>of an</u> <u>emergency</u> and activation <u>procedures of in ease of an</u> emergency <u>response may-should [?]</u> be clearly and visibly posted inside the facility at locations where they might be needed, and staff should be trained in these procedures (see <u>parasection</u>, 4.2.18 of Ref. [4950]).

<u>16.9.</u> The emergency plan for <u>a-the</u> radioisotope production facility should <u>includeaddress</u>, but not be limited to, scenarios such as theft of sources, on-site contamination or leaking due to damage of the source, accidental <u>radioactive</u> releases <u>into</u> the environment and overexposures of workers. Emergency procedures should include, but not be limited to: (a)-

- Protocols for notification of an emergency and activation protocols of an emergency response;
- <u>(b) cC</u>ommunication and coordination arrangements; (c)-
- <u>pP</u>rovisions for obtaining support from off-site emergency services; (d)-
- <u>p</u>Provision of instructions to the site personnel and provisions for accounting the site personnel; (e)-
- <u>dD</u>elineation of the affected area and access control; (f)-
- <u>mM</u>easures and actions to protect site personnel and emergency workers; and (g)-
- <u>Arrangements for communication with the public-etc.</u>

16.9. A qualified expert <u>RPA_or radiation protection adviser may_should [?]</u> be consulted, where possible, when drawing up emergency plans and procedures. Examples of immediate <u>on-site</u> actions to be taken in case of a<u>n</u> radiological emergency at a radioisotope production facility are given in Annex II. Formatted: Bulleted + Level: 1 + Aligned at: 0.5 cm + Indent at: 1.14 cm

Formatted: No bullets or numbering

16.10. Requirements and recommendations for on-site and off-site emergency preparedness and response are given in the IAEA safety standards [13, 47, 48] and Schedule IV of Ref. [3].[already stated] Technical guidanceRecommendations on developing adequate emergency arrangements at the organizational, local and national levels on a step by step basis is-are also available-provided from the IAEA-in GS-G-2.1 [487]. Technical-Further practical guidance regarding generic procedures for assessment and response during a radiological emergency is also availableprovided in Ref. [510].

16.11. Implementation of the on-site emergency plan and procedures may require off-site support (e.g. off-site response organizations, emergency services <u>and</u>, radiation protection specialists), as addressed in <u>Refs-GSR Part 7 [1315], and GS-G-2.1 [478]</u>. The emergency plan should <u>elaborate-set out detailed</u> arrangements for obtaining such off-site support.

16.12. <u>The Oo</u>perating organizations <u>isare</u> required to submit <u>for approval their its</u> on-site emergency plans to the regulatory body <u>for approval [4315]</u>. This is <u>required</u> to be done when applying for an authorization.

16.13. Emergency plans and procedures are required to be periodically reviewed and updated with the aim <u>to-of</u> incorporatinge lessons from research, operating experience (such as response to emergencies) and from exercises [1315].

EMERGENCY EQUIPMENT

16.14. Operators are The operating organization freally the operator? the requirement is on the government is required to ensure that all necessary tools, instruments, supplies, equipment, communication systems, facilities and documentation for responding to emergencies is are made available and are subjected to a quality management programme which that includes arrangements for inventoryies control, resupplies, testings and calibrations [4315]. All necessary tools, instruments, supplies, equipment, communication systems, facilities and documentation systems, facilities and documentation systems in the interval of the maintained in a manner that is readily available and functional for use under emergency conditions.

16.15. For emergencies involving radioisotope production sources, the following equipment should be considered, as appropriate:

-Appropriate and functional survey meters to measure both high and low dose rates;

Formatted: English (United States)
Formatted: Heading 2
Formatted: Highlight

—Personal alarm dosimeters and direct reading dosimeters (preferably electronic personal dosimeters);

—Additional personal dosimeters (<u>OSL-optically stimulated luminescence</u> dosimeters, thermoluminescent dosimeters and/or film badges);

-Personal protective equipment (PPE);

-Barrier materials and notices;

-Lead bricks;

—Suitable tool kits and source recovery equipment (long handleding tongs, pliers, screwdrivers, bolt cutters, adjustable spanner, torch, lead source storage container for sources);

—Materials and agents for decontamination [52+];

-<u>A</u>Spare shielded container;

—Plastic sheets, air tight bags for rupture of gaseous sources, <u>a</u> swipe test kit <u>and</u>, <u>a</u> measuring tape;

-Communication equipment (e.g. mobile phones);

--Spare batteries for survey meters, electronic personal dosimeters, mobile phones and torches;

-Pens, paper, calculator and an incident log book with first responder sheets;

-Equipment manuals, procedures and, instructions.

16.16. If it is suspected that a radioactive source might have been damaged, <u>consideration-it</u> should be <u>given to detectensured that</u> the leak <u>is detected</u> promptly and <u>to assess</u> the <u>extent of</u> <u>the [?]</u> contamination <u>is assessed</u> before being further spread out.

TRAINING AND EXERCISES

16.17. <u>All pP</u>ersonnel who have role and responsibilities in an who will participate in implementing the emergency response plans are required to be designated emergency workers and to be adequately qualified and trained for the effective fulfilment of their duties [1315]. This should include both familiarization with and understanding of the plans, procedures, analytical tools and other arrangements, together with specific training on implementing

Formatted: English (United States)

Formatted: Heading 2

specific emergency procedures and on the use of the emergency equipment, as appropriate. This is <u>also</u>-required to include guidance and training on the approximate radius of the inner cordoned off area in which urgent protective actions would initially be taken, and on the adjustment of this area on the basis of observed or assessed conditions on the site [1315].[are you sure about this last sentence? it is in para 5.44 of GSR part 7 and appears to apply only for category IV] Provisions for training should be reviewed periodically to ensure the continued proficiency of emergency workers.

16.18. Designated eEmergency workers should implement only those parts of the emergency plans or those emergency procedures for which they have been given authorityauthorized and responsibility and for which they have been trained.

16.19. Exercise programmes are required to be developed and implemented to ensure that all specified functions required to be performed forin an emergency response as well as organizational interfaces are tested at suitable intervals [4315]. Technical-gGuidance on the preparation, conduct and evaluation of exercises including technical-guidance on various types of exercises, their purpose, as well as examples of scenarios for category III facilities, can be found is provided in Ref. [498].

16.20. <u>Staff should be trained Training appropriately in emergency response, including should</u>* <u>cover the following</u>:

- (i) Recognizing the circumstances indicative of an emergency-situation;
- (ii) <u>Procedures for Nn</u>otification <u>of an emergency</u> and activation <u>procedures of an</u> <u>emergency response</u>, including provisions for obtaining assistance from off-site emergency services;
- (iii) Implementation of necessary on-site mitigatory actions and protective actions, onsite-including provision of <u>immediate</u> first aid, and <u>evacuation</u>-procedures for <u>evacuation of non-essential personnel from facility;</u>
- (iv) Assessment of the situation;
- (v) Use of emergency response tools and equipment including fire extinguishing gearfirefighting equipment and the rules of engagement; [what are the rules of engagement?]

Formatted: Indent: Before: 0 cm, First line: 0 cm, Tab stops: 1.25 cm, Left + Not at 1 cm

- (vi) Implementation of recovery actions, including decontamination;
- (vii) Measures to be followed for their protection during the emergency response.

16.21. Arrangements are required to be made to maintain, review and update emergency* plans, procedures and other arrangements and to incorporate lessons from research, operating experience (such as in the response to emergencies) and emergency exercises. Any lessons learned are required to be fed back into reviews and, as necessary, revisions of the emergency plans and procedures [1315]. [is this the requirement you're trying to refer to here?]

REPORTING

16.22. Arrangements are required to be made to undertake a timely and comprehensive analysis of <u>an-the</u> emergency and the emergency response [1315]. A comprehensive report on the findings of the analysis should be prepared by the <u>radiation protection officer RPO-in</u> consultation, as appropriate, with relevant interested parties and, if necessary, with qualified expert(s)/RPA or radiation protection adviser(s).

16.23. The report should be submitted to senior management as well as to the regulatory body and, as appropriate, to other relevant authorities at local, regional or national level. If the emergency could have been was [OK? it says below that the report includes the cause] caused by an equipment malfunction, the supplier and other users of similar equipment should be promptly informed so that the equipment can be evaluated and appropriate action taken and similar emergencies can be avoided.

16.24. The report should, inter alia, include the following:

- (a) A detailed description of the emergency, including specifics of the equipment and sources involved;
- (b) Environmental and working conditions at the time of the emergency, with particular reference to whether or not these conditions played any significant part in causing the emergency or affecting the outcome;
- (c) The root causes of the emergency;
- (d) A detailed description of the emergency response taken;
- (e) <u>The Pp</u>ersonnel involved, the work they carried out, <u>and their skills and qualifications;</u>

Formatted: Indent: Before: 0 cm, First line: 0 cm

Formatted: English (United States)

Formatted: Heading 2

- (f) An assessment and summary of the doses received by all affected individuals;
- (g) Corrective actions identified with the aim of preventing similar emergencies in the future and necessary for improving overall radiation safety, security and emergency arrangements; and
- (h) Proposed means and timeframes for implementation of the corrective actions identified and responsible staff.

REFERENCES

- [1] INTERNATIONAL ATOMIC ENERGY AGENCY, Manual for Reactor Produced Radioisotopes, IAEA TECDOC 1340Research Reactor Database (RRDB), IAEA, Vienna (201703),- https://nucleus.iaea.org/RRDB/RR/ReactorSearch.aspx
- [2] INTERNATIONAL ATOMIC ENERGY AGENCY, Directory of Cyclotrons Used for Radionuclide Production in Member States, 2006 UpdateRadiotherapy Centres (DIRAC), IAEA, Vienna (20062017)-, https://dirac.iaea.org/
- [3] EUROPEAN COMMISSION, FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR ORGANIZATION, OECD NUCLEAR ENERGY AGENCY, PAN AMERICAN HEALTH ORGANIZATION, UNITED NATIONS ENVIROMENT PROGRAMME, WORLD HEALTH ORGANIZATION, Radiation Protection and Safety of Radiation Sources: International Basic Safety Standards—General Safety Requirements Part 3, IAEA Safety Standards Series No. GSR Part 3, IAEA, Vienna (2014).
- [4] INTERNATIONAL ATOMIC ENERGY AGENCY, IAEA Safety Glossary: 2018607 Edition, IAEA, Vienna (201607in preparation).
- [4][5] INTERNATIONAL ATOMIC ENERGY AGENCY, IAEA Safety Standards Series No. SSR-3, Safety of Research Reactors, IAEA, Vienna (2016).
- [5][6] INTERNATIONAL ATOMIC ENERGY AGENCY, Nuclear Security Recommendations on Radioactive Material and Associated Facilities, IAEA Nuclear Security Series No. 14, IAEA, Vienna (2011).
- [6][7] INTERNATIONAL ATOMIC ENERGY AGENCY, Security of Radioactive Sources, IAEA Nuclear Security Series No. 11, IAEA, Vienna (2009).
- [7][8] INTERNATIONAL ATOMIC ENERGY AGENCY, Security in the Transport of Radioactive Material, IAEA Nuclear Security Series No. 9, IAEA, Vienna (2008).
- [8][9] INTERNATIONAL ATOMIC ENERGY AGENCY, Security of Nuclear Information, IAEA Nuclear Security Series No. 23-G, IAEA, Vienna (2015).
- [9][10] EUROPEAN ATOMIC ENERGY COMMUNITY, FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR ORGANIZATION, INTERNATIONAL MARITIME ORGANIZATION, OECD NUCLEAR ENERGY AGENCY, PAN AMERICAN HEALTH ORGANIZATION, UNITED NATIONS ENVIRONMENT PROGRAMME, WORLD HEALTH ORGANIZATION, Fundamental Safety Principles, IAEA Safety Standards Series No. SF-1, IAEA, Vienna (2006).
- [10][11] INTERNATIONAL ATOMIC ENERGY AGENCY, Categorization of Radioactive Sources, IAEA Safety Standards Series No. RS-G-1.9, IAEA, Vienna (2005).
- [11] INTERNATIONAL ATOMIC ENERGY AGENCY, Dangerous Quantities of Radioactive Material (D-Values), <u>EPR-D-Values (2006)</u>, IAEA, Vienna (2006).
- [13] INTERNATIONAL ATOMIC ENERGY AGENCY, Cyclotron Produced Radionuclides: Guidelines for Setting Up a Facility, Technical Reports Series No. 471, IAEA, Vienna (2009),
- [12]
 INTERNATIONAL
 ATOMIC
 ENERGY
 AGENCY,
 Governmental,
 Legal
 and

 Regulatory
 Framework for
 Safety,
 IAEA
 Safety
 Standards
 Series
 No.
 GSR
 Part 1 (Rev. 1),
 IAEA,
 Vienna (2016).
 Image: Contract of the series of th
- [13][15] COMPREHENSIVE NUCLEAR-TEST-BAN TREATY ORGANIZATION, FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL CIVIL AVIATION ORGANIZATION,

Formatted: Indent: Before: 0 cm, Hanging: 1 cm

Formatted: Font: (Asian) +Body (Calibri)

INTERNATIONAL LABOUR ORGANIZATION, INTERNATIONAL MARITIME ORGANIZATION, INTERPOL, OECD NUCLEAR ENERGY AGENCY, PAN AMERICAN HEALTH ORGANIZATION, UNITED NATIONS ENVIRONMENT PROGRAMME, UNITED NATIONS OFFICE FOR THE CO-ORDINATION OF HUMANITARIAN AFFAIRS, WORLD HEALTH ORGANIZATION, WORLD METEOROLOGICAL ORGANIZATION, Preparedness and Response for a Nuclear or Radiological Emergency, IAEA Safety Standards Series No. GSR Part 7, IAEA, Vienna (2015).

- [14][16] INTERNATIONAL ATOMIC ENERGY AGENCY, Leadership and Management for Safety, IAEA Safety Standards Series No. GSR Part 2, IAEA, Vienna (2016).
- [15][17] INTERNATIONAL ORGANIZATION FOR STANDARDIZATION, ISO 9001:2015 Quality Management Systems – Requirements, ISO (2015).
- [16][18] INTERNATIONAL ATOMIC ENERGY AGENCY, Application of the Management System for Facilities and Activities, IAEA Safety Standards Series No. GS-G-3.1, Vienna (2006).
- [17][19] FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR OFFICE, PAN AMERICAN HEALTH ORGANIZATION AND WORLD HEALTH ORGANIZATION. INTERNATIONAL ATOMIC ENERGY AGENCY, Regulatory Control of Radiation SourcesFunctions and Processes of the Regulatory Body for Safety, IAEA Safety Standards Series No. GS G 1.5GSG-13, IAEA, Vienna (2004in preparation).
- [18][20] INTERNATIONAL ATOMIC ENERGY AGENCY, Occupational Radiation Protection, IAEA Safety Standards Series No. <u>GSG-7-GS-G-7(in-publication)</u>, IAEA, Vienna (in preparation)(20187).
- [19][21] INTERNATIONAL ATOMIC ENERGY AGENCY, Safety Assessment for Facilities and Activities, IAEA Safety Standards Series No. GSR Part 4 (Rev. 1), IAEA, Vienna (2016).
- [20][22] INTERNATIONAL ATOMIC ENERGY AGENCY, Regulations for the Safe Transport of Radioactive Material, 20128 Edition, IAEA Safety Standards Series No. SSR-6 (Rev. 1), IAEA, Vienna (2012in preparation).
- [21][23] INTERNATIONAL ATOMIC ENERGY AGENCY, Radioisotope Handling Facilities and Automation of Radioisotope Production, IAEA-TECDOC-1430, IAEA, Vienna (2004).
- [22][24] NATIONAL COUNCIL ON RADIATION PROTECTION AND MEASUREMENTS, Radiation Protection for Particle Accelerator Facilities, Report No. 144, NCRP, Washington, DC (2003).
- [23][25] INTERNATIONAL ATOMIC ENERGY AGENCY, Radiological Safety Aspects of the Operation of Electron Linear Accelerators, Technical Reports Series No. 188, IAEA, Vienna (1979).
- [24][26] BRITISH STANDARDS INSTITUTION, Recommendation for Data on Shielding from Ionizing Radiation, Part 1: 1966, Shielding from Gamma Radiation, BS 4094, BSI, London (1988).
- [25][27] BRITISH STANDARDS INSTITUTION, Recommendation for Data on Shielding from Ionizing Radiation, Part 2: 1971, Shielding from X radiation, BS 4094, BSI, London (1988).
- [26][28] NATIONAL COUNCIL ON RADIATION PROTECTION AND MEASUREMENTS, Structural Shielding Design for Medical X-Ray Imaging Facilities, Report No. 147, NCRP, Bethesda, MD (2004).
- [27][29] INTERNATIONAL ATOMIC ENERGY AGENCY, Radiation Protection in the Design of Radiotherapy Facilities, Safety Reports Series No. 47, IAEA, Vienna (2006).

- [28][30] NATIONAL COUNCIL ON RADIATION PROTECTION AND MEASUREMENTS, Structural Shielding Design and Evaluation for Megavoltage X- and Gamma-Ray Radiotherapy Facilities, Report No. 151, NCRP, Washington, DC (2005).
- Evaluation
 Selection
 for
 Nuclear
 Installations,
 Specific
 Safety
 GuideIAEA
 Safety

 Standards
 Series
 No.
 SSG-3521,
 Vienna (20152).
- [32] INTERNATIONAL ATOMIC ENERGY AGENCY, Predisposal Management of Radioactive Waste, IAEA Safety Standards Series No. GSR Part 5, IAEA, Vienna (2009).
- [30][33] INTERNATIONAL ATOMIC ENERGY AGENCY, Implications for Occupational Radiation Protection of the New Dose Limit for the Lens of the Eye, IAEA-TECDOC-1731, IAEA, Vienna (2013).
- [31][34] INTERNATIONAL COMMISSION ON RADIATION PROTECTION, Dose Coefficients for Intakes of Radionuclides by Workers, ICRP Publication 68, Pergamon (1994).
- [32][35] INTERNATIONAL ATOMIC ENERGY AGENCY, Calibration of Radiation Protection Monitoring Instruments, Safety Reports Series No. 16, IAEA, Vienna (2000).
- [33][36] INTERNATIONAL ATOMIC ENERGY AGENCY, Regulatory Control of Radioactive Discharges to the Environment, IAEA Safety Standards Series No. <u>WS G 2.3 GSG-9 (in publication)</u>, IAEA, Vienna (201800in preparation). [DS4422]
- [34][37] INTERNATIONAL ATOMIC ENERGY AGENCY, Environmental and Source Monitoring for Purposes of Radiation Protection, IAEA Safety Standards Series No. RS-G-1.8, IAEA, Vienna (2005).
- [35][38] INTERNATIONAL ATOMIC ENERGY AGENCY, Generic Models for Use in Assessing the Impact of Discharges of Radioactive Substances to the Environment, IAEA Safety Reports Series No. 19, IAEA, Vienna (2001).
- [36][39] INTERNATIONAL ATOMIC ENERGY AGENCY, Decommissioning of Medical, Industrial and Research Facilities, IAEA Safety Standards Series No. SSG-49Draft Safety Standard DS403 (in preparation), IAEA, Vienna. (in preparation)
- [37][40] INTERNATIONAL ATOMIC ENERGY AGENCY, Decommissioning for of Facilities and Activities, IAEA Safety Standards Series No. GSR Part 6, IAEA, Vienna (2014).
- [38][1] INTERNATIONAL ATOMIC ENERGY AGENCY, Predisposal Management Radioactive Waste, IAEA Safety Standards Series No. GSR Part 5, IAEA, Vienna (2009).
- [39] INTERNATIONAL ATOMIC ENERGY AGENCY, The Safety Case and Safety Assessment for the Predisposal Management of Radioactive Waste, IAEA Safety Standards Series No. GSG 3, IAEA, Vienna (2013).[this is not cited]
- [40][41] INTERNATIONAL ATOMIC ENERGY AGENCY, Application of the Concepts of Exclusion, Exemption and Clearance, IAEA Safety Standards Series No. RS-G-1.7, IAEA, Vienna (2004).
- [41][42] INTERNATIONAL CIVIL AVIATION ORGANIZATION, Technical Instructions for the Safe Transport of Dangerous Goods by Air, 2015–2016 Edition, ICAO, Montreal (2014).
- [42][43] INTERNATIONAL MARITIME ORGANIZATION, International Maritime Dangerous Goods (IMDG) Code, 2014 Edition including Amendment 37–14, IMO, London (2014).
- [43][44] UNITED NATIONS ECONOMIC COMMISSION FOR EUROPE, INLAND TRANSPORT COMMITTEE, European Agreement Concerning the International Carriage of Dangerous Goods by Road (ADR), 2011 Edition, UNECE, Geneva (2011).
- [44][45] UNITED NATIONS ECONOMIC COMMISSION FOR EUROPE, INLAND TRANSPORT COMMITTEE, European Agreement Concerning the International Carriage of Dangerous Goods by Inland Waterways (ADN), 2011 Edition, UNECE, Geneva (2011).

Formatted: Font: 11 pt, Complex Script Font: 11 pt

- [45][46] The MERCOSUR/MERCOSUL Agreement of Partial Reach to Facilitate the Transport of Dangerous Goods, Signed by the Governments of Argentina, Brazil, Paraguay and Uruguay (1994).
- [46][47] INTERNATIONAL ATOMIC ENERGY AGENCY, Advisory Material for the IAEA Regulations for the Safe Transport of Radioactive Material₇ (2012 Edition), IAEA Safety Standards Series No. SSG-26, IAEA, Vienna (2012). (A revision of this publication is in preparation.)
- [47][48] FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR OFFICE, PAN AMERICAN HEALTH ORGANIZATION, UNITED NATIONS OFFICE FOR THE COORDINATION OF HUMANITARIAN AFFAIRS, WORLD HEALTH ORGANIZATIONINTERNATIONAL ATOMIC ENERGY AGENCY, Arrangements for Preparedness for a Nuclear or Radiological Emergency, IAEA Safety Standards Series No. GS-G-2.1, IAEA, Vienna (2007).
- [48][49] FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR OFFICE, PAN AMERICAN HEALTH ORGANIZATION AND WORLD HEALTH ORGANIZATION, Criteria for Use in Preparedness and Response for a Nuclear or Radiological Emergency, IAEA Safety Standards Series No. GSG-2, IAEA, Vienna (2011).
- [49][50] INTERNATIONAL ATOMIC ENERGY AGENCY, Method for Developing Arrangements for Response to a Nuclear or Radiological Emergency, EPR-Method (2003), IAEA, Vienna (2003).
- [50][51] INTERNATIONAL ATOMIC ENERGY AGENCY, Generic Procedures for Assessment and Response during a Radiological Emergency, IAEA-TECDOC-1162, IAEA, Vienna (2000).
- [51][52] INTERNATIONAL ATOMIC ENERGY AGENCY, State of the Art Technology for Decontamination and Dismantling of Nuclear Facilities, Technical Reports Series No. 395, IAEA, Vienna (1999).

ANNEX I

KEY RADIATION PROTECTION SAFETY ISSUES TO BE TAKEN INTO ACCOUNT WHEN PLANNING THE PRODUCTION OF ACCELERATOR BASED RADIOISOTOPES

<u>I-1.</u> <u>At the outset, the The production of radioisotopes accelerator building design should has to</u> comply with radiation safety requirements <u>on for protection of workers and the public</u>. Some of the key <u>aspects to be taken into account in planning the production of radioisotopesrequirements are listed belowin the following:</u>

 $\frac{1}{(a)}$ Material, process, and personnel flow diagrams that are important appropriate for the design of the facility:

- 2.(b) Appropriate shielding;
- 3-(c) Carefully designed mechanical, electrical, and utility requirements equipment [? not requirements?] for the operation of the cyclotron in the vault;
- 4.(d) <u>Ensure doors Doors</u> to high radiation areas have with interlocks;
- 5.(e) Negative pressure in the cyclotron vault:
- 6.(f) Adequately shielded hot cells;
- 7.(g) Air handling requirements equipment for the facility;
- 8.(h) Air pressure regimes in rooms and hot cells;
- 9.(i) Radiation monitoring provisions;
- 10.(j) An automated response system for engineering controls in the building:
- 11.(k) Provisions for <u>S</u>ecurity of radioactive materials;
- 12.(1) A Ddecommissioning plan and financial assurance for decommissioning;
- 13.(m) Application of Hhealth and safety requirements (e.g. fire protection, etc. requirements);
- 14.(n) Utility capacity (e.g. electric power, coolant, medical gases-ete.);
- 15.(o) <u>R&DResearch and development</u> requirementsneeds [?];
- 16.(p) Application of Ggood mManufacturing Ppractice requirements;
- 17.(q) <u>Receipt qProvision for quarantine of materials on receipt [?];</u>

18.(r) Verification of authorized that recipients of transferred radioactive material are authorized to receive such material;

- <u>19.(s)</u> Emergency planning and response.
- 20.(t) IT capacities and networksing;
- 21.(u) Redundancy;
- 22.(v) Quality control laboratories.

Formatted: Numbered + Level: 1 + Numbering Style: a, b, c, ... + Start at: 1 + Alignment: Left + Aligned at: 0.63 cm + Indent at: 1.27 cm

ANNEX II

EXAMPLE OF IMMEDIATE ON-SITE RESPONSE ACTIONS IN CASE OF AN EMERGENCY AT A RADIOISOTOPE PRODUCTION FACILITY

II_1.1. This Annex provides practical guidance for immediate on-site response actions that $\frac{\text{may}-\text{might}}{\text{may}-\text{might}}$ be warranted to be taken in case of an emergency at a radioisotope production facility by operating personnel and/or the RPO. Although the actions are listed in the sequence in which they can be expected to generally be performed, it may be necessary that they beto implemented these actions in another sequence or simultaneously. These actions are generic and focused only on those that are immediately warranted on-site. They do not take into account for all the emergency response actions that may-might be warranted off the -site and for those actions that may-might be warranted beyond these immediate actions on the site, as required stated in EPR-related IAEA Safety Standards and practical guidance [II_-1] to-[II_-4IV].

II______. Operating personnel:

- (a) Recognizes promptly abnormal conditions at the site that <u>is are</u> indicative of an emergency and activates the pre-planned emergency response;
- (b) Takes lifesaving actions and gives first aid;
- (c) Evacuates non-essential personnel and visitors from the potentially hazardous area;
- (d) Establishes an inner cordoned off area and prevents any access;
- Notif<u>yies</u> relevant authorities (on <u>the</u>-site and off <u>the</u>-site), including the radiation protection officer-(RPO);
- (f) Measures the radiation dose rates and records any doses measured by direct reading dosimeters;
- (g) Re-adjusts the inner cordoned off area if necessary;
- (h) Keeps the area always attended until the respective-the designated emergency workers and the radiation protection officer [??] arrive.

II_<u>-3</u>III. The <u>radiation protection officer</u>RPO:

- Monitors on-site personnel and visitors for contamination and ensures <u>that</u> contaminated individuals and items do not leave <u>the site undetected and contaminated items are not</u> removed from the site undetected;
- (b) Recommends decontamination of individuals and items, as appropriate, <u>following-in</u> accordance with<u>respective</u> emergency procedures;
- (c) Confirms whether off-site protective actions are needed;
- (d) Ensures <u>a</u> unified command and control system is established as pre-planned to manage the emergency response;
- (e) Recommends a specific course of action on the basis of previously established emergency procedures, taking care to adequately protect emergency workers and on-site personnel as well as to minimize their doses;
- (f) If <u>needednecessary</u>, rehearses the planned course of action with respective emergency workers before entering the inner cordoned off area to implement the emergency plan;
- (g) Implements, along with designated emergency workers, the planned course of action;
- (h) If necessary, calls for technical assistance from a qualified expert <u>RPA</u> or radiation protection adviser and/or from the manufacturer of equipment;
- (i) Ensures that the access control to the inner cordoned_-off area is in place at all times;
- (j) As appropriate, notifies senior management and the regulatory body and ensures continuous communication with off-site authorities.

REFERENCES TO ANNEX II

- [II_-1]- INTERNATIONAL ATOMIC ENERGY AGENCY, Arrangements for Preparedness for a Nuclear or Radiological Emergency, IAEA Safety Standards Series No. GS-G-2.1, IAEA, Vienna (2007).
- [II-244]- FOOD AND AGRICULTURE ORGANIZATION OF THE UNITED NATIONS, INTERNATIONAL ATOMIC ENERGY AGENCY, INTERNATIONAL LABOUR OFFICE, PAN AMERICAN HEALTH ORGANIZATION AND WORLD HEALTH ORGANIZATION, Criteria for Use in Preparedness and Response for a Nuclear or Radiological Emergency: General Safety Guide, IAEA Safety Standards Series No. GSG-2, IAEA, Vienna (2011).

[II_III3-] INTERNATIONAL ATOMIC ENERGY AGENCY, Method for Developing Arrangements for Response to a Nuclear or Radiological Emergency, EPR-Method (2003), IAEA, Vienna (2003).

[II_-IV4-] INTERNATIONAL ATOMIC ENERGY AGENCY, Generic Procedures for Assessment and Response during a Radiological Emergency, IAEA-TECDOC-1162, IAEA, Vienna (2000).

CONTRIBUTORS TO DRAFTING AND REVIEW

Formatted: Heading 1

Asfaw, K.E.	International Atomic Energy Agency	
Blackley, R.	Australian Nuclear Science and Technology Organisation, Australia	
Castellanos Macchiorlato, A.	National Atomic Energy Commission, Argentina	Formatted: Font: 11 pt, Complex Script Font: 11 pt
Fisher, D.	Pacific Northwest National Laboratory, United States of America	Formatted: Font: 11 pt, Complex Script Font: 11 pt
Geets, J-M.	Ion Beam Applications s.a., Belgium	Formatted: Font: 11 pt, Complex Script Font: 11 pt
Gusev, I.	International Atomic Energy Agency	
Haridasan, P.P.	International Atomic Energy Agency	Formatted: Font: 11 pt, Complex Script Font: 11 pt
Hertgers, K.	Consultant. The Netherlands	Formatted: Font: 11 pt, Complex Script Font: 11 pt
Jensen, M.	Riso National Laboratory for Sustainable Energy, Denmark	 Formatted: Font: 11 pt, Complex Script Font: 11 pt
Karev, A.	Federal Medical Biophysical Center of A.I. Burnazyana, Russian Federation	
Kochnov, O	Research and Scientific Institute of Physical Chemistry, Russian Federation	
Mukherjee, B.	Duisburg-Essen University, Germany	 Formatted: Font: 11 pt
Nauser, T.	Eidgenössische Technische Hochschule, Switzerland	Formatted: Font: 11 pt
O'Donnell, R.	Consultant, Ireland	
Rajashekharrao, B.	Bhabha Atomic Research Centre, India	
Reber, E.	International Atomic Energy Agency	
Utkin, K.	State Atomic Energy "ROSATOM", Russian Federation	
	CONSULTANTS MEETINGS	

CONSULTANTS MEETINGS

2 4 December 2008, IAEA, Vienna

9 13 December 2013, IAEA, Vienna

20-24 April 2015, IAEA, Vienna

28 September 2 October 2015, IAEA, Vienna

100